

and personal information. And it could also be full of your work-related critical data, especially if you're syncing with work-based email, contacts, calendars and documents. Don't be a statistic.

Locking the phone is easy, as is unlocking when you want to use it. To enable a lock, navigate to **All Programs > Settings > Lock & Wallpaper**. From this interface, you can change the wallpaper and personalise it if you want. Here's also where you configure other features related to locking the phone. Windows Phone supports exactly one kind of password: a four-digit numeric PIN, similar to what you use in ATMs. Memorise it and ensure that it's not immediately obvious to others. To add a lock to the phone, switch the Password option to On. Then, type in the password/PIN you'd like to use. Windows Phone will prompt you to type it twice just to make sure you get it right. Then check out the Screen Time Out option. This setting, which can be set to 30 seconds, 1 minute, 3 minutes or 5 minutes, determines how long the screen remains active after you last tapped it. Once this time elapses, the screen shuts off and the lock is activated.

There are actually some additional features you can configure to work when the screen is locked. And these features can't be accessed from Lock & Wallpaper, so you really have to dig deep to find them.

- ▶ **The phone's integrated camera:** By default, you can configure the camera's on-device button to wake up the phone when pressed. But maybe you don't want that for some reason. To disable this feature, navigate to **All Programs > Settings > Applications > Pictures + Camera**. The very first option on this settings screen is "Allow the Camera Button to Wake Up the Phone". If you would prefer this to be off, just change it to Off.
- ▶ **Windows Phone's incredible speech functionality:** While the phone is on, you can hold down the Start button for a few seconds to trigger the speech interface; just speak a command: "open calendar" "call Pavan at home" or anything at all and the phone will begin doing your bidding. By default, the speech feature won't work when the screen is locked. So if the phone is off and you hold down the Start button for a few seconds, nothing will happen. But if you navigate to **All Programs > Settings > Speech** you'll find an option titled "Use Speech When the Phone Is Locked". Just check that option and you're good to go. Enabling speech when the phone is locked isn't as clear cut as the camera setting, however. That's because depending on the design of your particular phone and