

your usage patterns, it's possible for the phone to inadvertently trigger the speech feature when the button was pressed while in your pocket or bag. You've heard of "pocket dialing", for sure. Welcome to pocket speech command. Test this feature if you think it will be useful. And pay attention to any suspicious battery drain or angry blank call recipients.

► **Find My Phone:** Microsoft offers a free service called Find My Phone that will help you recover a lost or stolen Windows Phone. There are a couple of on-phone settings related to Find My Phone that might be of interest in the context of locking your phone. That is, Find My Phone works best when it can actually find your phone. And while you can manually try to find a lost or stolen phone from the web, seconds count. So if you navigate to **All Programs > Settings > Find My Phone**, you can enable two options:

- **Save My Location Periodically for Better Mapping:** It's a must if you think that there's any chance of you losing your phone.
- **Use Push Notification:** This could be more of a problem than a benefit. That's because pushing your location info from the phone can be battery intensive, especially if you're moving around a lot. So this could drain the battery prematurely.

From the Find My Phone web service, one of the things you can do is lock the phone's screen remotely.

Use Windows Phone in Flight Mode

Many smartphones have a special master on-off switch for all wireless features called Flight Mode, and in this regard Windows Phone is no different. It's so named because flights prohibit the use of wireless equipment on a plane while it's taxi-ing or flying. But phone users would like to use their devices' non-network functionality, to play music or enjoy a game while in-flight.

On Windows Phone, you access this mode called the Airplane Mode here at **All Programs > Settings > Airplane Mode**. In this interface, you'll see a single Radios on/off



The Airplane mode a.k.a the Flight Mode