

may be supported on the server. But if you use an address with a supported account type (gmail.com, live.com and so on), Windows Phone will properly configure it and give you the option to enable and disable whichever services are supported by that account type.

- ▶ **Advanced Account setup:** This account type starts off like Other Accounts, but rather than try to auto-detect the server settings, it will step you through a more advanced manual configuration. After entering the username and password of the account you'd like to set up, you must choose between Exchange ActiveSync or an internet email account which can be either a POP3 or an IMAP-based account only.

Wi-Fi sync

This configuration is actually made from the Zune PC software, but since it's deeply tied to the overall configuration of the phone, it makes sense to cover it. Generally speaking, you connect your Windows Phone to the PC for just a few reasons: To sync photos taken with the phone's camera to the PC, to sync your PC-based media collection to the phone, to install large software updates and so on.

Each of these actions requires you to physically connect the phone to the PC using a USB-based PC sync cable. But Windows Phone, like the Zune HD before it, supports a more automatic way to perform these same actions. Microsoft calls this feature wireless sync, but since it can only work over a Wi-Fi wireless network (and not over cellular or Bluetooth connections) the name Wi-Fi sync makes more sense. Wi-Fi sync is brilliant in its simplicity: Since many today have a Wi-Fi-based home network, and since many most likely bring their phone home every day to charge it, chances are that your PC and phone will be in close proximity to each other and connected (at least, wirelessly) to the home network. So instead of forcing you to explicitly tether the phone to the PC, you can instead just configure the phone to sync over Wi-Fi. And it will happen automatically, as long as you plug the phone into a wall outlet for charging.

First, you must connect your phone to the home network's Wi-Fi connection and the phone's Wi-Fi functionality must be enabled. Then, connect your phone to the PC using the USB sync cable. This is only for this configuration step. Next open the Zune PC software and navigate to **Settings > Phone > Wireless Sync**. This will trigger a short wizard. In the first and only step of this wizard, you must confirm the network that