

towards the centre. The reverse action (swiping down with two fingers) will minimise the keyboard. You can also minimise the keyboard by holding your finger on the space bar for a couple of seconds.

Keyboard tips

- ▶ Quickly delete a word by swiping across the keyboard from right to left. The word to the left of the cursor is deleted.
- ▶ Swipe down from the top of the keyboard with a single finger to change the keyboard view to text, symbols or numbers (depending on the current view).
- ▶ Hold down the shift key to change the keyboard to CAPS lock.
- ▶ To add special accented characters such as when writing déjà vu, you can hold down the key in question (E to get é, for example) and then slide your finger to the desired accented character when it appears and release your finger.
- ▶ While typing, you will see suggested words appearing on different onscreen keys. These suggested words can help you type a lot faster. All you need to do to type out the suggested word is to swipe up from the letter in question – in an action that's similar to flicking the word to the screen. For example, when you want to type out the sentence, “The quick brown fox jumps over the lazy dog.” All you need to do is type “T ~h~ ~q~ ~b~ ~f~ ~j~ ~o~ ~t~ ~l~ ~d~”, where the “~h~” signifies a swipe up from the letter H. As you can see, this means you can type out the sentence a lot quicker than normal.
- ▶ Touch and hold the full stop key to start voice dictation. Not really ideal for the Indian accent, but if you speak clearly without using too much Indian colloquialism, it can do a pretty decent job.
- ▶ Autocorrect is a little different from the suggested words. If the



The Autocorrect feature