

and the additional settings icon (three vertical dots). You will also see a thumbnail of the last photograph you clicked, and tapping on this will take you to your photo library.

First we'll look at the camera icon – it's basically a quick way of changing between the still camera, video camera, and what BlackBerry calls Time Shift Mode. The settings icon will display additional settings that you can change based on which of the aforementioned modes you've chosen. Let's look at the various modes and the settings associated with them.

Time Shift Mode

A lot of smartphone OSes offer such a feature now, and this basically lets the phone click a scene in a quick burst, and then allows you to swipe through the scene to select the best possible shot. The phone will automatically detect faces in the image, and then allow you to go through a short interval of captures to allow you to find the best still image for that face. You repeat this for all the visible faces, and then save your image. This helps a lot when you click a group picture and find that one (or more) people blinked just at the moment you clicked. Instead of putting everyone through the inconvenience of retaking the picture, you now just use Time Shift Mode to make sure you get a shot with everyone's eyes open. Understand that this is different from selecting a still from a video, for example, because in a video you could find that every frame has someone or the other blinking (eyes closed), and there'd be nothing you could do about it. With Time Shift you get to choose the best shot for every individual's face. More on using this feature later in the book.

In the additional menu settings when in this mode you will see: Switch Camera (toggle between rear and front cameras), the Scene option (default is Auto, but you can also select Action, Whiteboard, Night and Beach or Snow, depending on the surroundings), and Aspect Ratio (1:1, 4:3 or 16:9).

Video Camera

The video camera is pretty straightforward on all phones, and it's no different here. By default image stabilisation is turned on (which is ideal). If you click on additional settings you will see that you get the option to: Switch Camera, change Shooting Mode (Normal and Stabilisation), choose the Scene (Auto, Night and Beach or Snow), you also get an option to turn the LED light (also acts as a flash in still photography) on or off, and of course you get to select the video size (1080p or 720p).