

camera allows you to increase or decrease the exposure over what it assumes to be the ideal exposure for a particular scene. It allows you to overexpose or underexpose a scene as desired over the default value. You will see the default value as zero in the middle on the exposure scale, and you can increase or decrease it in stops like -2, -1, 0, 1 and 2. In simple terms, it lets you brighten or darken a scene.

At times a camera may overexpose a scene by default. This is where you can use exposure compensation to dial down the exposure a bit and achieve correct level of illumination for the scene where things are neither too bright with clipped highlights nor too dark. It is one of the more useful tools available on a camera and wise use of it can achieve really good results.

Metering Mode

This is related to exposure and determines the way the camera adjusts its exposure for a particular scene. There are usually three types of settings here that you can choose from. There is spot metering, where the camera will determine the correct exposure for a particular scene depending upon a small spot in the center of the screen. You can often change the location of this spot by tapping elsewhere on the screen (which also changes the focus point). Now depending upon how light or dark that spot is, the camera will determine the overall exposure of the image, ignoring everything else.

Then there is center-weighted average, which is usually the default setting. Here, the camera will look at the subjects in the center of the frame and then base the overall exposure on that. This is usually default because it



Metering can help you get greater control over exposure