

2. Seat the GPU in the top x16 slot; connect the required PCIe power (use the included 12VHPWR adapter or native cable if your PSU supports it).
3. Connect monitor over DisplayPort (preferred for PC high-refresh) or HDMI 2.1.
4. Boot and install the latest NVIDIA/AMD driver (and chipset drivers).

Turn on the big three (Windows + driver suites):

1. **Windows Game Mode & Auto HDR** → Windows Settings ► Gaming ► Game Mode On; Windows Settings ► System ► Display ► HDR On, Auto HDR On.
2. **VRR on PC displays**
 - **G-SYNC** (NVIDIA Control Panel ► Set up G-SYNC) or in the newer NVIDIA app, enable G-SYNC/G-SYNC Compatible.
 - **FreeSync** (AMD Software ► Display ► FreeSync On).
3. **Resizable BAR / Smart Access Memory** for extra GPU throughput
 - **NVIDIA:** update GPU VBIOS if needed and enable Resizable BAR in motherboard BIOS; verify in NVIDIA Control Panel (System Information → “Resizable BAR: Yes”).
 - **AMD:** enable SAM in BIOS (often under PCIe/Above 4G Decoding/Resizable BAR).

Quick profiles:

- **1440p/144 Hz sweet spot:** RTX 4070 Ti SUPER / RX 7900 XT or newer; enable DLSS/FSR and VRR.
- **4K/120 “no-compromise”:** RTX 5080/5090, or Radeon RX 9070 XT where supported; paired with a 4K/120 FreeSync/G-SYNC display and a modern CPU.

Controllers & input

1) Picking the right pad

- **PS5 DualSense / DualSense Edge:** Hallmark haptics and adaptive triggers; the Accessories app on Windows lets you update firmware and configure the Edge.



EXAMPLE BUILDS & BUYS

Console-first, cinema-second:

- PS5 Pro + 55–65" 4K/120 TV with HDMI 2.1 and VRR; enable Adjust HDR/VRR on PS5; add an internal M.2 SSD later.

Subscription-led, family setup:

- Xbox Series X + Game Pass Standard/Ultimate (India pricing in INR), plus a WD_BLACK C50 1TB card when storage runs out.

PC 1440p/144 Hz all-rounder:

- Ryzen 7 9700X or Intel Core Ultra 7 Arrow Lake, RTX 4070 Ti SUPER / RX 7900 XT, 32 GB DDR5, 1–2 TB NVMe. Turn on Game Mode/Auto HDR, VRR (G-SYNC/FreeSync), and Resizable BAR/SAM.

4K/120 enthusiast PC:

- Core Ultra 9 / Ryzen 9, RTX 5080/5090 or RX 9070 XT, 32–64 GB RAM. Enable frame-gen (DLSS or FSR) plus Reflex/AFMF.

- **Xbox Wireless Controller / Elite Series 2:** Broad PC/console support, excellent ergonomics, and deep customization via the Xbox Accessories app.
- **Nintendo Switch 2 Pro Controller:** Official controller with motion, rumble, and remappable GL/GR buttons for the new system.
- **Third-party (8BitDo, etc.):** Many models now offer Hall-effect sticks to resist drift; check the model specs.
- **Accessibility:** Xbox Adaptive Controller and PlayStation Access controller are widely documented and supported.

2) Step-by-step: remap on PC (for any game)

On Steam (Windows/Linux):

1. Open Steam Big Picture Mode ► Settings ► Controller ► Controller Settings.
2. Register your controller and enable the appropriate support (Xbox/PlayStation/Switch).
3. For each game, open Controller Layout and map buttons, set dead-zones, and gyro.

On Windows (Xbox controllers):

1. Install Xbox Accessories from Microsoft Store.
2. Connect your controller (USB/Xbox Wireless adapter/Bluetooth).