

14. Put the shaft and its end-stop back to original position (apply some petroleum jelly on shaft inner side), as shown in Fig. 14.

Modification

15. For modification, solder the rivet back in its position, as shown in Fig. 15. Spin the shaft to ensure it rotates easily.

16. De-solder the wires from the driver board, as shown in Fig. 16.

17. Mount two resistors to make the driver sense that the potentiometer is always on its centre position. The resistors should be of 1% tolerance to ensure the precision required. The value of the resistors should be 2.2-kilo-ohm each, and 0805 package, as shown in Fig. 17.

Re-assembly

18. Re-assemble all the parts of gear assembly in their correct order (refer to the previously-clicked pictures of the gear assembly), as shown in Fig. 18.

19. Push potentiometer back into



Fig. 18: Re-assembling the gears



Fig. 19: Assembling the potentiometer inside case

the case, as shown in Fig. 19. Do not try to rotate the gear assembly at this time.

20. Put back the PCB inside the case. Ensure that all the wires properly



Fig. 20: Modified servo motor

fit inside the housing and none of them is getting pinched. Put the screws back and the servo motor is ready, as shown in Fig. 20. ●

The author is working as an assistant manager at Samtel Avionics Ltd

support@ efy.in

**Do you have a query,
suggestion or a complaint?**

**You can e-mail it to
support@efy.in
and we will take care
of the rest.**



electronics
www.electronicsforu.com

ELECTRONICS
BAZAAR
www.eb.efyindia.com

OpenSource
FOR YOU
www.opensourceforu.com

Facts
FOR YOU
www.fymag.com

EFY
SERVING YOURS
www.efy.in