

TABLE II
Raspivid Options

Commands	Functions
Image Parameter Commands	
-w, --width	Set image width <size>, Default 1920
-h, --height	Set image height <size> Default 1080
-b, --bitrate	Set bitrate. Use bits per second (for example, 10MBits/s would be -b 10000000)
-o, --output	Output filename <filename> (to write to stdout, use '-o -'). If not specified, no file is saved
-v, --verbose	Output verbose information during run
-t, --timeout	Time (in ms) before it takes picture and shuts down (if not specified, set to 5s)
-sh, --sharpness	Set image sharpness (-100 to 100)
-co, --contrast	Set image contrast (-100 to 100)
-br, --brightness	Set image brightness (0 to 100)
-sa, --saturation	Set image saturation (-100 to 100)
-rot, --rotation	Set image rotation (0-359)
-hf, --hflip	Set horizontal flip
-vf, --vflip	Set vertical flip
Preview Parameter Commands	
-p, --preview	Preview window settings <'x,y,w,h'>
-f, --fullscreen	Full-screen preview mode
-op, --opacity	Preview window opacity (0-255)
-n, --nopreview	Do not display a preview window

```
pi@raspberrypi ~ $ sudo apt-get install mplayer netcat
```

Fig. 5: Installing mplayer and netcat

```
pi@raspberrypi ~ $ raspivid -t 5000000 -o - | nc [your IP] 5001
```

Fig. 6: Feed to mplayer

```
pi@raspberrypi ~ $ raspivid -t 5000000 -o - | nc [your IP] 5001
```

Fig. 7: Sending the video to port 5001

Pi using the command (also refer Fig. 5):

```
$ sudo apt-get install  
mplayer netcat
```

You need to set up the Windows computer to receive transmission from the Raspberry Pi. So open command prompt and go to the directory where you have extracted mplayer and netcat. Type:

```
nc -l -p 5001 | mplayer fps  
31 -cache 1024 -
```

```
Raspivid -t 999999 -o - | nc [yourIP]  
5001
```

This will take the video and send it to port 5001

When you go back to the computer, you will see the command prompt. Hit Enter key and the video starts streaming. You will see mplayer icon at the bottom-right corner of the window. Click it and you can see live footage. ●

The author is working as an assistant manager at Samtel Avionics Ltd

DO YOU HAVE EXCITING SOFTWARE FOR ELECTRONICS DESIGN ENGINEERS?

Get it bundled with the
EFY PLUS DVD

To know more: contact Atul (+91-8800094211)
or write to us at efyeng@efyindia.com

