

file and runtime support library. Set the basic build options for the linker and compiler, and set up the target configuration.

4. Click 'Finish.' A new project has now been created. The 'C/C++ Projects' window contains Temperature_Indicator. The project is set as 'Active' and the output files are located in 'Debug' folder. At this point, the project does not include any source file. The next step is to add the source files to the project.

5. To add a source file to the project, right-click 'Temperature_Indicator' in 'C/C++ Projects' window and select New→Source File. Name the source file as main.c and click 'Finish' button. An empty window will open for the main.c code. You can enter the code here. We have used the original source code that is designed for the MSP430G2231 and included in EFY DVD.

6. Click 'File→Open File' and navigate to 'C:\MSP430\EFY\Files.' Open

the 'Temperature_Indicator.txt' file. Copy and paste its contents into main.c. Save main.c by clicking 'Save' button in the upper left side of the CCS window.

7. Click 'Build' and watch the tools run in 'Console' window. Make sure that no errors are listed in 'Problems' window. The program output with '.out' extension will be generated in 'Debug' folder.

Programming hardware tool setup.

In this step, you flash/program the MCU. You need a programmer for that. Either use the TI LaunchPad or the TI EZ430 dongle as a programmer. The Web link to LaunchPad is:

http://processors.wiki.ti.com/index.php/MSP430_LaunchPad_%28MSP-EXP430G2%29?DCMP=launchpad&HQ=Other+PR+launchpadwiki-pr

The link to EZ430 is:

<http://focus.ti.com/docs/toolsw/folders/print/ez430-f2013.html>

Burning the code into MSP430 is straightforward with MSP430 Launch-

EFY Note

The source code of this project is included in this month's EFY DVD and is also available for free download on www.efymag.com website.

Pad and CCSv5 as explained below.

MSP430 LaunchPad setup. The LaunchPad board includes a preprogrammed MSP430G2231 device that is already located in the target socket. When the LaunchPad is connected to your PC via USB, the demo starts with an LED toggle sequence. The on-board emulator generates the supply voltage and all of the signals necessary to start the demo. The driver installation starts automatically. If prompted, allow Windows to install the software automatically.

At this point, the on-board red and green LEDs should be in a toggle sequence. This lets you know that the hardware is working and has been setup correctly. Now, copy and paste the temperature_Indicator.txt file as



RIGHT SOLUTION PROVIDER



E&I TRANSFORMERS



MIRACLE ELECTRONIC DEVICES PVT LTD.

Regd. Office : # 48/1, Korikobanahalli Village, Thigalarapally Main Road,
Penny 2nd Stage, Bangalore - 560 058, (India)
Tel: +91 80 28362750/ 51 | Fax: +91 80 2836 2752
sale@miracle.net.in | www.toroidal.com

on DGS&D RC



*The non-stop
power performer*
Since 1988



Digital online UPS-up to 500 KVA • Table Top UPS-up to 3 KVA

Servo Voltage Stabilizer-up to 2500 KVA

Wall Mountable Voltage Stabilizer • Digital Inverter Sine Wave

CVT • Tubular Battery • Solar Inverter



Supra Hi-tech Electro Equipments Pvt Ltd

Supra House, Chakkaraparambu, NH Bypass Cochin 682 032.
Tel: 91 484 2333880, 2342679, 2330906, Fax: 91 484 2337132
Mobile: 09447136456, Email: info@suprahiotech.com

www.suprahiotech.com