



Fig. 14: Tool for Web server checking



Fig. 15: Success

Finding out the IP address of your computer is very simple. Open Internet browser and type 'http://www.whereismyip.com/'. In reply, you will get your IP address on your computer screen; for example, 'http://17.199.145.228' is the IP address of our PC.

Note that your IP address changes frequently, especially when your computer reboots. To overcome this problem, you have to use static IP address by purchasing it from your Internet provider. You can also use any of the Dy-

namic DNS Services freely available on the Internet. Some of them are DNSdynamic, DNSEXIT and NO-IP. For more details, visit respective websites 'http://www.dnsdynamic.org/', 'http://www.dnsexit.com/' and 'http://www.no-ip.com/'. We have used DNSEXit Service and automatic IP Updater software of DNSEXit for this project.

Set up DNS and domain name

You can also give a name of your Web server with login on free DNS Service. For this, proceed as follows:

1. Open the website of DNSEXIT by typing 'http://www.dnsexit.com/'.
2. Click 'Sign Up' option to open an account, then login with your user ID and password.
3. Click 'login,' then see free second-level domains. Click 'Setup DNS,' then click 'DNS Express' and type your domain name as 'efywebserver.' Uncheck the box "IP address is dynamic," then click "Create DNS" followed by "Verify DNS."

Now click 'Dyn DNS Clients,' download Windows IP Updater 2.0 and install it in your computer. After installation, reboot your computer. You will see IP Updater running automatically and your Web server working.

Checking of your Web server

To check your Web server and webpage on the Internet, you can use 'Open Port Check Tool.' Open Internet browser and type Web address 'http://www.canyouseeme.org/'. You will get a screen as shown in Fig. 14. Click 'Check.' You will get another screen with 'Success' as shown in Fig. 15. This shows that your Web server is running fine. In case of any error, check and repeat the above procedure.

EFY note. We have used BSNL's broadband ADSL modem type B2 AN1020-20. For other ADSL modem, read its user manual for configuration of port forwarding, DMZ and virtual server. ●

The author is a regular contributor to EFY