

the door switch wire that turns the dome or courtesy lamp 'on' and any accessory wire that is powered by the battery when the ignition switch is turned on.

After locating these wires, use a multimeter to verify the voltage levels at each terminal. Door switch wire should be at 12V when the door is closed and at zero volt when the door is open. The accessory wire is at 12V only when the ignition switch is turned on. The ignition coil works only when the ignition switch is 'on.' After verifying the proper voltage levels, disconnect the negative (chassis ground) wire from the car battery. This will ensure that any inadvertent short circuit occurring during installation will not cause any damage. Connect the module with dome light and accessory wire.

Secure the anti-carjack module at the desired location, then mount the LEDs and reset switch S1 such that the LEDs are visible to the driver, but the

reset switch is hidden.

Locate the power line that goes to the ignition coil section. Cut the line as shown in the wiring diagram (Fig. 2) and connect with N/C contact and pole of relay RL1. Finally, connect ground lead of the circuit to any metal part of the car. After making all the connections, reconnect the negative (chassis ground) battery lead securely. This completes installation of the anti-carjack system.

Final test. When the installation is complete, make sure that both the LEDs are 'off.' If LED2 glows, press reset switch S1 to put it off. Now start the vehicle. When the engine is running, open the door and then close it. LED1 should glow. After a minute, it should go off and LED2 should glow. The vehicle engine will stall and you won't be able to restart it. Press reset switch S1 and verify that both the LEDs are 'off.' Now you should be able to restart the vehicle.

The anti-carjack module is always on-duty, fully automatic and never in need of attention. Always remember to turn off the ignition switch before leaving the vehicle. If at any time, the circuit is accidentally triggered as indicated by LED1, wait for LED2 to glow and then press reset switch S1 to put it off. The vehicle will always protect itself in the event of carjack attempt while the ignition switch is 'on.'

Further application

You can also use this project to protect your car from theft. If at any time you wish to enable the system before leaving the vehicle, open the door before turning the ignition switch 'off.' LED1 will glow to indicate that the circuit has been activated. Wait a minute for LED2 to glow, which indicates that the relay is energised and the vehicle disabled. Remember, you must press reset switch S1 before starting the engine when you return. ●

Spanning The Height Of Heights



Tell Me More About Advertising Opportunities in EFY Magazine

I am aware that EFY Magazine presents umpteen advertising opportunities. I too would like to explore the various options available for my organisation, so that I can help it grow in terms of sales and brand presence. My details are mentioned below:

Name _____
Organisation _____
Designation _____
Address _____
City _____ Pincode _____
Phone _____ Fax _____
E-mail _____

I would like to have a one-to-one meeting

- ☐ I would like to have a one-to-one meeting with someone from the EFY team.
☐ Please send me your marketing kit containing all necessary details.

Please mail/fax this form to:



EFY Enterprises Pvt Ltd

D-87/1, Okhla Industrial Area, Phase-I, New Delhi 110020

Tel: 011-26810601/2/3; Fax: 011-26817563

Email: efymkt@efyindia.com; Website: www.efyindia.com