

0013	9000 31 FF 91		LXI SP,STACK		0085	90AC D3 00	OUT DAT(8279)	
0014	9003 3E 80		MVI A,80H ;8255 Control word for		0086	90AE 21 50 93	LXI H,PATTERN5 ;Pattern5 location 9350H	
0015	9005 D3 0B		OUT CWR(8255)		0087	90B1 0E 08	MVI C,08 ;No. of data in pattern5	
0016	9007 CD CC 90	LOOP:	CALL MESSAGE ;Call subroutine for		0088	90B3 CD B9 90	CALL DISPLAY	
			message display		0089	90B6 C3 9F 90	JMP P5	
0017	900A CD 64 0A		CALL RKBKD ;An utility subroutine		0090	90B9 7E	DISPLAY: MOV A,M ;display subroutine	
			in the kit to Accept hex		0091	90BA D3 08	OUT PORTA ;aacc content in port A	
			digit form the keyboard.		0092	90BC D3 09	OUT PORTB ;aacc content in port B	
0018	900D FE 11		CPI 11H ;Compare with next key		0093	90BE D3 0A	OUT PORTC ;aacc content in port C	
			code		0094	90C0 CD E1 90	CALL DELAY	
0019	900F C2 07 90		JNZ LOOP		0095	90C3 CD E1 90	CALL DELAY	
0020	9012 CD 00 0B		CALL CLEAR ;Clear display		0096	90C6 23	INX H ;point to next memory	
0021	9015 CD 64 0A	CHECK:	CALL RKBKD				location	
0022	9018 B6 0F		ANI 0FH		0097	90C7 0D	DCR C	
0023	901A FE 01		CPI 01H		0098	90C8 C2 B9 90	JNZ DISPLAY	
0024	901C CA 37 90		JE P1		0099	90CB C9	RET	
0025	901F FE 02		CPI 02H		0100	90CC		
0026	9021 CA 31 90		JE P2		0101	90CC		
0027	9024 FE 03		CPI 03H		0102	90CC 3E 04	MESSAGE: MVI A,04H ;mode setting of 8279	
0028	9026 CA 4B 90		JE P3		0103	90CE 13 01	OUT CWR(8279) ;control word for 8279	
0029	9029 FE 04		CPI 04H		0104	90D0 3E 79	MVI A,79H ;7 SEGMENT CODE FOR 'M'	
0030	902B CA 85 90		JE P4		0105	90D2 D3 00	OUT DAT(8279) ;display acc content	
0031	902E FE 05		CPI 05H		0106	90D4 CA 5E	MVI A,5EH ;7 SEGMENT CODE FOR 'd'	
0032	9030 CA 9F 90		JE P5		0107	90D6 D3 00	OUT DAT(8279) ;display acc content	
0033	9033 C3 15 90		JMP CHECK		0108	90D8 3E 3F	MVI A,3FH ;7 SEGMENT CODE FOR 'O'	
0034	9036 76		HLT		0109	90DA D3 00	OUT DAT(8279) ;display acc content	
0035	9037 CD 00 0B	P1:	CALL CLEAR ;Pattern1 subroutine		0110	90DC 3E 39	MVI A,39H ;7 SEGMENT CODE FOR 'C'	
0036	903A 3E 20		MVI A,20H ;mode setting of 8279		0111	90DE D3 00	OUT DAT(8279) ;display acc content	
0037	903C D3 01		OUT CWR(8279) ;control word for 8279		0112	90E0 19	RET	
0038	903E 3E 06		MVI A,06H ;7 SEGMENT CODE FOR '1'		0113	90E1 11 FF FF	DELAY: LXI D,OFFFHH ;Delay subroutine	
0039	9040 D3 00		OUT DAT(8279) ;display acc content		0114	90E4 18	L2: DCR D	
0040	9042 3E 73		MVI A,73H ;7 SEGMENT CODE FOR 'p'		0115	90E5 7B	MOV A,E	
0041	9044 D3 00		OUT DAT(8279)		0116	90E6 B2	ORA D	
0042	9046 21 10 93		LXI H,PATTERN1 ;Pattern1 location 9310H		0117	90E7 C2 E4 90	JNZ L2	
0043	9049 DE 08		MVI C,08H ;No. of data in pattern1		0118	90EA C9	RET	
0044	904B CD B9 90		CALL DISPLAY		0119	90EB		
0045	904E C3 37 90		JMP P1		0120	90EB	ORG 9310H	
0046	9051 CD 00 0B	P2:	CALL CLEAR ;Pattern2 subroutine		0121	9310 80	PATTERN1: DB 80H	
0047	9054 3E 20		MVI A,20H ;mode setting of 8279		0122	9311 50	DB 50H	
0048	9056 D3 01		OUT CWR(8279) ;control word for 8279		0123	9312 20	DB 20H	
0049	9058 3E 5B		MVI A,5BH ;7 SEGMENT CODE FOR '2'		0124	9313 10	DB 10H	
0050	905A D3 00		OUT DAT(8279) ;display acc content		0125	9314 08	DB 08H	
0051	905C 3E 73		MVI A,73H ;7 SEGMENT CODE FOR 'p'		0126	9315 05	DB 05H	
0052	905E D3 00		OUT DAT(8279)		0127	9316 02	DB 02H	
0053	9060 21 20 93		LXI H,PATTERN2 ;Pattern2 location 9320H		0128	9317 01	DB 01H	
0054	9063 DE 06		MVI C,06H ;No. of data in pattern2		0129	9318	ORG 9320H	
0055	9065 CD B9 90		CALL DISPLAY		0130	9320 55	PATTERN2: DB 55H	
0056	9068 C3 51 90		JMP P2		0131	9321 AA	DB 0AAH	
0057	906B CD 00 0B	P3:	CALL CLEAR ;Pattern3 subroutine		0132	9322 CC	DB 0CCH	
0058	906E 3E 20		MVI A,20H ;mode setting of 8279		0133	9323 33	DB 33H	
0059	9070 D3 01		OUT CWR(8279) ;control word for 8279		0134	9324 00	DB 0F0H	
0060	9072 3E 4F		MVI A,4FH ;7 SEGMENT CODE FOR '3'		0135	9325 0F	DB 0FH	
0061	9074 D3 00		OUT DAT(8279) ;display acc content		0136	9326	ORG 9330H	
0062	9076 3E 73		MVI A,73H ;7 SEGMENT CODE FOR 'p'		0137	9330 81	PATTERN3: DB 81H	
0063	9078 D3 00		OUT DAT(8279)		0138	9331 42	DB 42H	
0064	907A 21 30 93		LXI H,PATTERN3 ;Pattern3 location 9330H		0139	9332 24	DB 24H	
0065	907D DE 06		MVI C,06H ;No. of data in pattern3		0140	9333 18	DB 18H	
0066	907F CD B9 90		CALL DISPLAY		0141	9334 24	DB 24H	
0067	9082 C3 4B 90		JMP P3		0142	9335 42	DB 42H	
0068	9085 CD 00 0B	P4:	CALL CLEAR ;Pattern4 subroutine		0143	9336	ORG 9340H	
0069	9088 3E 20		MVI A,20H ;mode setting of 8279		0144	9340 81	PATTERN4: DB 81H	
0070	908A D3 01		OUT CWR(8279) ;control word for 8279		0145	9341 18	DB 18H	
0071	908C 3E 66		MVI A,66H ;7 SEGMENT CODE FOR '4'		0146	9342 42	DB 42H	
0072	908E D3 00		OUT DAT(8279) ;display acc content		0147	9343 24	DB 24H	
0073	9090 3E 73		MVI A,73H ;7 SEGMENT CODE FOR 'p'		0148	9344	ORG 9350H	
0074	9092 D3 00		OUT DAT(8279)		0149	9350 7F	PATTERN5: DB 07FH	
0075	9094 21 40 93		LXI H,PATTERN4 ;Pattern4 location 9340H		0150	9351 BF	DB 0BFH	
0076	9097 DE 04		MVI C,04H ;No. of data in pattern4		0151	9352 DF	DB 0DFH	
0077	9099 CD B9 90		CALL DISPLAY		0152	9353 EF	DB 0EFH	
0078	909C C3 85 90		JMP P4		0153	9354 7F	DB 07FH	
0079	909F CD 00 0B	P5:	CALL CLEAR ;Pattern5 subroutine		0154	9355 FB	DB 0FBH	
0080	90A2 3E 20		MVI A,20H ;mode setting of 8279		0155	9356 FD	DB 0FDH	
0081	90A4 D3 01		OUT CWR(8279) ;control word for 8279		0156	9357 FE	DB 0FEH	
0082	90A6 3E 6D		MVI A,6DH ;7 SEGMENT CODE FOR '5'		0157	9358	.END	
0083	90A8 D3 00		OUT DAT(8279) ;display acc content					
0084	90AA 3E 73		MVI A,73H ;7 SEGMENT CODE FOR 'p'					

Number of errors = 0