



Fig. 5: Circuit diagram of receiver circuit

- Integrated antenna
- Edge connector

Software features. These are:

- Slave default baud rate: 9600, data bits: 8; stop bit: 1; parity: no parity
- Auto-connect to the last device on power as default
- Permits pairing device to connect as default
- Auto-pairing pin: 1234 as default

Pin description. HC-05 Bluetooth module has six pins, as detailed below.

Enable. When enable is pulled low, the module is disabled. This means the module will not turn on and will fail to communicate. When enable is left open or connected to 3.3V, the module is enabled, that is, it will

remain on and communication will also take place.

Vcc. Supply voltage 3.3V to 5V.

Gnd. Ground pin.

Txd and Rxd. These pins act as UART interface for communication.

State. This pin acts as the status indicator. When the module is not connected to or paired with any other Bluetooth device, the signal goes low. At this low state, the onboard LED flashes continuously, which denotes that the module is not paired with another device. When this module is connected to or paired with another Bluetooth device, the signal goes high. At this high state, the onboard LED blinks with a constant delay of, say, two seconds. This indicates that the module is paired.