

after their power is turned off.

Now the setup is complete and the wireless remote is ready to use.

Software program

Three programs (HC-05_config.slave.ino, TX-rem-cont.ino and RX-rem-cont.ino) are used in this project.

HC-05_config.slave.ino is used to configure Bluetooth slave module, TX-rem-cont.ino is used for transmitter Arduino and RX-rem-cont.ino is used for receiver Arduino.

You need Arduino IDE software to compile and upload these codes into their respective Arduino boards.

Main functions of Arduino codes are explained below:

pinMode() . Configures the specified pin to behave either as an input or an output. See digital pin descriptions for detailed pin functionalities.

digitalWrite() . If the pin is

PARTS LIST	
Semiconductors:	
D1-D6	- 1N4007 rectifier diode
T1-T6	- 2N2222 npn switching transistor
Board1, Board2 - Arduino Uno board	
BT1, BT2	- HC-05 Bluetooth module
Resistors (all 1/4-watt, ±5% carbon):	
R1-R6	- 10-kilo-ohm
R7-R12	- 2.2-kilo-ohm
Miscellaneous:	
S1-S6	- Tactile switch
CON1, CON2	- 6-pin female connector
CON3	- 2-pin terminal connector
CON4-CON9	- 3-pin connector for relays
RL1-RL6	- 12V, 1CO relay
M1-M3	- 12V, 50rpm DC motor
BATT.1, BATT.2	- 9V battery with connector
BATT.3	- 12V battery
	- 11-pin connector for Board1
	- 10-pin connector for Board2
Jack 1, Jack 2	- DC jack
	- Castor wheel
	- Male-to-male jumper wires
	- CP2102 converter

configured as an OUTPUT with pin-Mode(), its voltage will be set to the corresponding value: 5V (or 3.3V on 3.3V boards) for HIGH, 0V (ground) for LOW.

digitalRead() . Reads the

value from a specified digital pin, either HIGH or LOW.

available() . Gets the number of bytes (characters) available for reading from the serial port. This is the data that has already arrived and is stored in the serial receive buffer (which holds 64 bytes). available() inherits from the Stream utility class.

begin() . Sets the data rate in bits per second (baud) for serial data transmission. For communicating with the computer, use one of these rates: 300, 600, 1200, 2400, 4800, 9600, 14400, 19200, 28800, 38400, 57600 or 115200. You can, however, specify other rates. For example, to communicate over digital pins 0 and 1 of Arduino that requires a particular baud rate.

println() . Prints data to the serial port as human-readable ASCII text followed by a carriage return character.


For the 'engineer' in you



DON'T MISS THIS MEGA OPPORTUNITY

Become A Dealer OR Seller Of India's #1 Educational Kits Brand & Grow Your Business Manifold!

How to Become a Seller on kitsNspares.com



```

graph LR
    A[Registration] --> B[Sign Partnership]
    B --> C[Set Up Your Online Shop]
            
```

Registration
Complete the kitsNspares.com seller registration process by Providing the required information and documents.

Sign Partnership
Sign the agreement after providing documents.

Set Up Your Online Shop
Upload Your Inventory with Offers and start selling

How to Become a Dealer on kitsNspares.com



```

graph LR
    A[Registration] --> B[Sign Partnership]
    B --> C[Set Up Your Online Shop]
            
```

Registration
Complete the dealer registration process by Providing the required information and documents.

Sign Partnership
Sign the agreement after providing documents.

Set Up Your Online Shop
Upload Your Inventory with Offers and start selling

D-87/1, Okhla Industrial Area, Phase 1, New Delhi 110020 | Phone: +91-8800100761, +91-11-26371661 E-Mail: sales@kitsnspares.com