

TataSky Ch Plus code

TataSky Ch minus code

TataSky Remote Codes					Sony TV Remote Codes		
Encoding	RC6 24bits		Encoding	RC6 24bits		Encoding	Sony 12 bit
Key	Code		Key	Code		Key	Code
Power	C0000C		Fav	C0003C		Power	A90
TV	C00080		Back	C00083		Input	A50
Home	C00084		Help	C00081		Vol+	490
Guide	C000CC					Vol-	C90
Showcase	C0007D		Red	C0006D		Ch+	890
Organiser	C0007E		Green	C0006E		Ch-	290
Active	C000F5		Yellow	C0006F			
Mute	C0000D		Blue	C00070			
i	C000CB						
Vol+	C00010		1	C00001			
Vol-	C00011		2	C00002			
Ch+	C00020		3	C00003			
Ch-	C00021		4	C00004			
^	C00058		5	C00005			
v	C00059		6	C00006			
<	C0005A		7	C00007			
>	C0005B		8	C00008			
Select	C0005C		9	C00009			

The diagram shows a NodeMCU ESP8266 board (BOARD2) with a Wi-Fi chip. The board is connected to a 5V power supply (I/P1 = 230V AC) via a 5V pin. The board also has a USB PWR INPUT and a 3V pin. The board is connected to two IR LEDs (IRTX1, IRTX2) via a 5V pin. The LEDs are connected to ground (GND) through resistors R1 (10E) and R2 (10E). The LEDs are also connected to the board's pins D0 (30), D1 (29), D2 (28), D3 (27), D4 (26), D5 (25), D6 (24), D7 (23), D8 (22), D9 (21), D10 (20), D11 (19), D12 (18), D13 (17), and D14 (16) through resistors R3 (1K), R4 (1K), and R5 (1K). The LEDs are labeled IRTX1 and IRTX2, and the output is labeled IRTX1, IRTX2 = IR TRANSMITTER LED.

A white, rectangular electronic device, possibly a small amplifier or speaker, is shown. It has a speaker grille on the front and a small control knob. The device is mounted on a circular base.

on the wall opposite the place where the TV set and the set-top box have been placed. Please ensure that the IR beam has an unobstructed path to the TV and set-top boxes. If possible, one can use a 3D printer to print a suitable enclosure and mount it on a wall or room ceiling. The author's prototypes are shown in Fig. 11 and Fig. 12.

Download the Arduino sketch (*WiFiRemoteVer1.4.ino*) from the EFY website. Since the prototype has been built

On boot-up, the NodeMCU connects to the home Wi-Fi network. You need to enter your Wi-Fi SSID and the corresponding password in the sketch. Since each time the IR-Blaster boots up the router may allocate a new IP address to it, it is better to have a known fixed IP address. The user may, depending on his router hardware, either reserve an IP address (using DHCP address reservation) or use the software method shown below.

is not used by any other node on your network.