



Fig. 9: Trimming the aileron, elevator, throttle, and rudder values to zero



Fig. 10: Flight controller in armed position

position and turn the RC transmitter on. Connect the battery to the drone and power the drone. Now the flight controller turns on and we can see the display showing either safety or error on the controller LCD.

Using the buttons on the flight controller, as shown in Fig. 7, go to menu and select the Motor Layout type using Down button. Select the x quad motor layout, confirm the selection, and press the back button. Note that the flight controller unit should be attached to the F450 frame properly.

Accelerometer calibration

Put your drone on a flat surface, making sure the flight controller is stable and not tilted to any side. Press the menu button and using up/down button go to 'Acc calibration'

option as shown in Fig. 8. Select the option and then press the select button again to continue. Wait for a few seconds for the flight controller to automatically calibrate the accelerometer and then show 'ok to go' on the display.

Flight controller uses signals from the radio receiver and passes these signals, together with stabilisation signals, to control the drone via the aileron, elevator, throttle, and rudder user inputs.

On the receiver side,

check the rudder, elevator, throttle, and other values. If any value is more than zero, use the trim option in the remote transmitter. Trim the value to zero as shown in Fig. 9. Once the value gets trimmed, the drone is ready to fly.

Testing

To start the flight, called arming, keep the throttle stick in transmitter to lower left for a few seconds and then increase the throttle slowly to full. The display will show Armed as shown in Fig. 10. The drone is ready to fly now.

To land the drone, decrease the throttle and disarm it by taking the throttle stick to lower right. **EFY**

Ashwini Kumar Sinha is an electronics hobbyist and tech journalist at EFY

India's
No. 1
Electronics
Magazine
RANKING AS PER
ELCINA-IMRB
REPORT

Don't Be A Loser!

You don't know how much you don't know.

Read

electronics
FOR YOU

to keep up-to-date with the tech world

To subscribe, visit efy.in or contact us at: 011-4059660
Email: support@efy.in

OR

Scan This Code

Also available at all leading magazine outlets