

Input Source: Machine

The general properties available for all inputs are described in the [Input Properties](#) topic.

Properties

General

Name

Input1

Description

Data Type

Char

☒ Char

☐ Integer

☐ Decimal

☐ Boolean

☐ DateTime

☐ Complex

☒ Scalar

☐ List

☐ List (Iterate)

☐ List (Duplicate)

☒ Use Source Value Copy

Input Source

Machine

Machine Integrator Processing

☐ Client (Browser)

☒ Web Server

Machine Source

☒ Point Alias

☐ Equipment

Point Alias

☐ None

☒ Constant

☐ Session Variable

☐ Previous Function Output

☐ System Parameter

Constant value

The Machine Input functionality is supported in the Screen Flows client mode. For more information, refer to [Screen Flows client mode](#).

Machine Input of type List (Iterate) is iterated by its values (array of Points values read from machine) and not by properties settings of FI DFC/Step.

Field	Description
Machine Integrator Processing	▶ Client (Browser) – Value is read directly from the Machine Integrator Connector by the Client’s Browser. This Connector can be running on the same computer as the browser or on a remote one. ▶ Web Server – Value is read from Machine Integrator Connector by the Web server when processing DFC.

	Usage details are explained in the <i>Machine Integrator Guide</i> .
Machine Source	The user may reference an actual MI Point by its Point Alias or by providing Equipment and its Attribute to which the Point is mapped.
Point Alias	The alias of a point configured with DELMIA Apriso Machine Integrator. Point Alias: ▶ None ▶ Constant ▶ Session Variable ▶ Previous Function Output ▶ System Parameter

Machine Integrator Processing: Web Server

The screenshot shows the 'Properties' dialog box for 'Machine Integrator Processing'. The 'General' tab is selected. The 'Name' field is 'Input1'. The 'Description' field is empty. The 'Data Type' section shows 'Char' selected. The 'Use Source Value Copy' checkbox is checked. The 'Input Source' dropdown is set to 'Machine'. The 'Machine Integrator Processing' section has 'Web Server' selected. The 'Machine Source' section has 'Point Alias' selected. The 'Point Alias' section has 'Constant' selected, and the 'Constant value' field is empty.

Properties

General

Name
Input1

Description

Data Type
Char

☒ Char ☒ Scalar
☐ Integer ☐ List
☐ Decimal ☐ List (Iterate)
☐ Boolean ☐ List (Duplicate)
☐ DateTime
☐ Complex

☒ Use Source Value Copy

Input Source
Machine

Machine Integrator Processing
☐ Client (Browser) ☒ Web Server

Machine Source
☒ Point Alias ☐ Equipment

Point Alias
☐ None ☒ Constant ☐ Session Variable
☐ Previous Function Output ☐ System Parameter

Constant value

Machine Integrator Processing: Client (Browser)

Make sure that the DELMIA Apriso Client with the Client Machine Integrator is installed in order to be able to use this functionality. For more information, see the ***DELMIA Apriso Installation Guide***.

General Tab

The screenshot shows the 'Properties' dialog box with the 'General' tab selected. The 'User Input Properties' sub-tab is also visible. The configuration is as follows:

- Name:** Input1
- Description:** (Empty text area)
- Data Type:** Char (selected in the dropdown)
- Radio Buttons for Data Type:**
 - ☒ Char
 - ☐ Integer
 - ☐ Decimal
 - ☐ Boolean
 - ☐ DateTime
 - ☐ Complex
 - ☒ Scalar
 - ☐ List
 - ☐ List (Iterate)
 - ☐ List (Duplicate)
- ☒ Use Source Value Copy
- Input Source:** Machine (selected in the dropdown)
- Machine Integrator Processing:**
 - ☒ Client (Browser) (highlighted with a red box)
 - ☐ Web Server
- Machine Source:**
 - ☒ Point Alias
 - ☐ Equipment
- Point Alias:**
 - ☐ None
 - ☒ Constant (highlighted with a red box)
 - ☐ Session Variable
 - ☐ Previous Function Output
 - ☐ System Parameter
- Constant value:** (Empty text box)
- User Control Visibility:**
 - ☒ Hidden (highlighted with a red box)
 - ☐ Read Only
 - ☐ Editable
- Initial Value:**
 - ☐ None
 - ☒ Constant (highlighted with a red box)
 - ☐ Session Variable
 - ☐ Previous Function Output
 - ☐ System Parameter
- Constant value:** (Empty text box)
- Input Value Mode:**
 - ☒ Current (highlighted with a red box)
 - ☐ After Change
 - ☐ After Change or From Buffer
- ☐ Populate on startup
- ☐ Value is Required

Field	Description
User Control Visibility	Type of User Control Visibility. The user can choose between: Hidden, Read Only, or Editable. Usage details are explained in the <i>Machine Integrator Guide</i> .
Initial Value	The Initial Value can be chosen from different sources and is displayed depending on the chosen Input data type (the system suggests an example of the data format). To keep backward compatibility, the Initial Value will also be used when no value is present in the Input (this works like a default value).
Input Value Mode	Input Mode – sets the Input mode based on the options below: ▶ Current – Machine Integrator returns current point value ▶ After Change – Machine Integrator returns point value after it has changed ▶ After Change or From Buffer – Machine Integrator returns the point value after it has changed or from the buffer (previous value) Populate on startup check box – Check box becomes active, after setting Input Mode to After Change or After Change or From Buffer. When selected, the current value from the source will be read as soon as a client connects to Machine Integrator. Usage details are explained in the <i>Machine Integrator Guide</i>.
Value is Required check box	If this check box is selected, a value must be entered.

User Input Properties Tab

Properties

General User Input Properties

Device	Prompt
▶ Desktop	Input 1
Mobile	Input 1

Control properties for device

Formatting

☐ CSS-based
☒ Direct

Prompt

Font...

☐ Hide Prompt

Value

Font...

Attributes...

Layout and icon

Layout

Simple

Icon

(None)

Navigation

☐ Hide OK button
☐ Auto Submit

Position

☐ Absolute Position

Offset

Alignment

Horizontal

0

Left

Vertical

0

Top

Properties

General User Input Properties

Device	Prompt
▶ Desktop	Input 1
Mobile	Input 1

Control properties for device

Formatting

☒ CSS-based
☐ Direct

Prompt:

Prompt

Font...

☐ Hide Prompt

Value:

Text

Attributes...

Layout and icon

Layout

Simple

Icon

(None)

Navigation

☐ Hide OK button
☐ Auto Submit

Position

☐ Absolute Position

Offset

Alignment

Horizontal

0

Left

Vertical

0

Top

Field	Description
User Interface Prompts	The prompts associated with the Function Input you are defining. ▶ Desktop – the prompt string (text) to be used with this Input as rendered on a desktop browser ▶ Mobile – the prompt string (text) to be used with this Input as rendered on a mobile browser Mobile and Text platforms are no longer supported.
Control properties for device	If Desktop or Mobile is selected, the following options are available: ▶ Hide Prompt check box – if selected, the prompt will not be displayed ▶ Attributes button – opens a pop-up window for the configuration of additional HTML attributes ▶ Formatting ▷ Direct – enables the defining of fonts, colors, etc. for the prompt for the user of a desktop or mobile device: ▶ Prompt – the formatting that applies to the desktop prompt string ▶ Value – the formatting that applies to the desktop value field ▷ CSS-based – the user can specify a CSS class to be used for an Input: ▶ Prompt ▶ Value
Layout and icon	Layout – defines the layout of the values will be. There are three types of layouts: ▶ Simple ▶ Tabular ▶ Horizontal Icon – an icon that is displayed to the immediate left of the input prompt on desktop and mobile devices. Available icons include: ▶ Information ▶ Question ▶ Warning ▶ Error
Navigation	Navigation – used to control the submission of the screen: ▶ Auto Submit – auto submit the page ▶ Hide OK button
Position	If the Absolute Position check box is selected, the user may change the position of the control in Layout Editor. The user specifies the offset (in pixels) and the alignment of the control.

Machine Source: Equipment

Properties

General

Name
Input1

Description

Data Type
Char

☒ Char
 ☒ Scalar
☐ Integer
 ☐ List
☐ Decimal
 ☐ List (Iterate)
☐ Boolean
 ☐ List (Duplicate)
☐ DateTime
☐ Complex

☒ Use Source Value Copy

Input Source
Machine

Machine Integrator Processing
☐ Client (Browser)
 ☒ Web Server

Machine Source
☐ Point Alias
 ☒ Equipment

Equipment
☒ None
☐ Constant
☐ Session Variable
☐ Previous Function Output
☐ System Parameter

Facility
☒ None
☐ Constant
☐ Session Variable
☐ Previous Function Output
☐ System Parameter

Attribute
☒ None
☐ Constant
☐ Session Variable
☐ Previous Function Output
☐ System Parameter

The user may reference an actual MI Point by providing Equipment with Facility and its Attribute to which the Point is mapped.

The Facility Input is optional except from the situation when there are two Equipment entities

The link between Equipment, its Attribute and MI Point can be configured within [Machine Integrator Configuration](#) or [Equipment Explorer](#) Screens.

The time needed to reflect changes in configuration (linking another Machine Integrator Point to equipment) depends on time set in "CacheValidationDelay" key located in the "Framework" section of the Central Configuration file (for details, see [Central Configuration Documentation](#)).