

Output Destination: Machine

The general properties available for all outputs are described in the [Output Properties](#) topic.

Properties

General

Name

Output2

Description

Data Type

Char

☒ Char

☐ Integer

☐ Decimal

☐ Boolean

☐ DateTime

☐ Complex

☐ Scalar

☐ List

Default Value

Routing Dispositions

User

External

Session

Machine

Remove

Type	Comment
User	
Machine	

Machine Integrator Processing

☐ Client (Browser)

☒ Web Server

Machine Source

☒ Point Alias

☐ Equipment

Point Alias

☐ None

☒ Constant

☐ Session Variable

☐ Previous Function Output

☐ System Parameter

Constant value

The Machine Output functionality is supported in the Screen Flows client mode. For more information, refer to [Screen Flows client code](#).

Field	Description
Machine Integrator Processing	▶ Client (Browser) – The value is written directly from the Client’s Browser to the Machine Integrator Connector. This Connector can be running on the same computer as the browser or on a remote one.

	▶ Web Server – The value is written by the Web Server to the Machine Integrator Connector after submitting the page.
Machine Source	The source of the value that links the Output to the Machine Integrator Point may be: ▶ Point Alias ▶ Equipment
Point Alias Source	The point alias linking this Output to DELMIA Apriso Machine Integrator. The list of Point Alias Sources is: ▶ None ▶ Constant ▶ Session Variable ▶ Previous Function Output ▶ System Parameter

Machine Source: Equipment

Properties

General

Name
Output1

Description

Data Type
Char

☒ Char
 ☐ Scalar
☐ Integer
 ☐ List
☐ Decimal
☐ Boolean
☐ DateTime
☐ Complex

Default Value

Routing Dispositions

User External

Session Machine Remove

Type	Comment
Machine	

Machine Integrator Processing

☒ Client (Browser)
 ☐ Web Server

Machine Source

☐ Point Alias
 ☒ Equipment

Equipment

☒ None
☐ Constant
☐ Session Variable
☐ Previous Function Output
☐ System Parameter

Facility

☒ None
☐ Constant
☐ Session Variable
☐ Previous Function Output
☐ System Parameter

Attribute

☒ None
☐ Constant
☐ Session Variable
☐ Previous Function Output
☐ System Parameter

The link between Equipment, its Attribute and MI Point can be configured within [Machine Integrator Configuration](#) or [Equipment Explorer](#) Screens.

The time needed to reflect changes in configuration (linking another Machine Integrator Point to equipment) depends on time set using "CacheValidationDelay" key located in the "Framework" section of the Central Configuration file (for details, see [Central Configuration Documentation](#)).