Hydraulic pump service interval
Replace the pump seals every 2000 operating hours.
Use seal kit HK-77 and check the relief valve at 180 bar.