

1) Write a testcases on pen.

Test Case Number	Test Case Name	Objective/Summary	Pre-Requisite/Primary Condition	Steps To Be Followed	Test Data	Expected Result
TC_PEN_001	Verify pen writes smoothly	Verify smooth ink flow during writing	Pen contains ink	1.Open cap 2.Write on paper	Blue Pen	Pen should write smoothly without interruption
TC_PEN_002	Verify pen ink color	Verify pen writes in correct color	Pen available	1.Write on white paper	Black Pen	Ink color should match pen type
TC_PEN_003	Verify pen cap fitting	Verify cap closes properly	Pen cap available	1.Close cap on pen	Ball Pen	Cap should fit tightly
TC_PEN_004	Verify pen leakage	Verify ink does not leak	Pen filled with ink	1.Keep pen in pocket for few hours	Gel Pen	No ink leakage should occur
TC_PEN_005	Verify writing after long idle time	Verify pen works after long unused duration	Pen unused for 7 days	1.Try writing on paper	Blue Ink Pen	Pen should write within few strokes
TC_PEN_006	Verify pen grip comfort	Verify grip usability	Pen available	1.Hold pen 2.Write continuously	Rubber Grip Pen	Grip should feel comfortable
TC_PEN_007	Verify broken tip handling	Verify functionality after tip damage	Tip slightly damaged	1.Try writing	Damaged Pen Tip	Writing quality should reduce or fail
TC_PEN_008	Verify refill replacement	Verify refill replacement functionality	Compatible refill available	1.Open pen 2.Replace refill	Cello Refill	Pen should work after refill replacement
TC_PEN_009	Verify writing on glossy paper	Verify pen writes on glossy surface	Glossy paper available	1.Write on glossy paper	Glossy Sheet	Pen should write properly
TC_PEN_010	Verify waterproof ink	Verify ink resistance to water	Waterproof pen available	1.Write on paper 2.Drop water	Waterproof Marker	Ink should not spread
TC_PEN_011	Verify pen durability after drop	Verify pen works after accidental fall	Pen available	1.Drop pen from table 2.Try writing	Ball Pen	Pen should still function
TC_PEN_012	Verify pocket clip strength	Verify clip holds properly	Pen with clip available	1.Attach pen to pocket	Pocket Pen	Clip should not break
TC_PEN_013	Verify low ink warning signs	Verify faint writing when ink low	Low ink pen	1.Write continuously	Almost Empty Pen	Ink should become lighter gradually
TC_PEN_014	Verify child safety cap design	Verify safety hole in cap	Pen cap available	1.Check cap design	Child Safe Pen	Cap should contain safety hole
TC_PEN_015	Verify fast writing support	Verify smooth writing at high speed	Pen available	1.Write quickly for 1 page	Fast Writing Test	Ink should not skip during fast writing

2) Write testcases on tv.

Test Case Number	Test Case Name	Objective/Summary	Pre-Requisite/Primary Condition	Steps To Be Followed	Test Data	Expected Result
TC_TV_001	Verify TV power ON	Verify TV powers on correctly	TV connected to power supply	1.Press power button	Remote Power Button	TV should turn ON
TC_TV_002	Verify TV power OFF	Verify TV shuts down correctly	TV is ON	1.Press power button	Remote Power Button	TV should turn OFF
TC_TV_003	Verify channel change using remote	Verify user can switch channels	TV channels configured	1.Press channel up/down button	Channel 101 to 102	Channel should change successfully
TC_TV_004	Verify volume increase	Verify volume up functionality	TV is ON	1.Press volume up button	Volume +	Volume should increase
TC_TV_005	Verify volume mute functionality	Verify mute option works	TV is ON	1.Press mute button	Mute Button	Audio should mute
TC_TV_006	Verify HDMI connection	Verify HDMI device connectivity	HDMI cable connected	1.Select HDMI source	HDMI 1	Connected device display should appear
TC_TV_007	Verify invalid HDMI source	Verify behavior for disconnected HDMI	No HDMI device connected	1.Select HDMI source	HDMI 2	No Signal message should display
TC_TV_008	Verify WiFi connectivity	Verify TV connects to WiFi	WiFi available	1.Open network settings 2.Connect to WiFi	WiFi Password: abc@123	TV should connect successfully
TC_TV_009	Verify invalid WiFi password	Verify validation for wrong WiFi password	WiFi available	1.Enter incorrect password	Password: fsjf123	Connection should fail
TC_TV_010	Verify YouTube app launch	Verify YouTube app opens correctly	Internet connected	1.Open YouTube app	YouTube App	YouTube should launch successfully
TC_TV_011	Verify app crash handling	Verify TV handles app crash safely	Streaming app installed	1.Open app repeatedly	Netflix App	TV should not freeze completely
TC_TV_012	Verify screen brightness adjustment	Verify brightness settings functionality	TV is ON	1.Open display settings 2.Change brightness	Brightness 80%	Screen brightness should change
TC_TV_013	Verify USB media playback	Verify TV plays USB media files	USB device connected	1.Open USB media	Movie.mp4	Video should play successfully
TC_TV_014	Verify unsupported media file	Verify unsupported file handling	USB connected	1.Play unsupported file	abc.xyz	Unsupported format message should display
TC_TV_015	Verify remote battery low response	Verify remote functionality with low battery	Low battery remote	1.Try changing channels	Low Battery Remote	Remote response may slow but should work
TC_TV_016	Verify parental control lock	Verify parental lock functionality	Parental lock enabled	1.Open restricted channel	PIN: 1234	PIN request should appear
TC_TV_017	Verify invalid parental PIN	Verify validation for wrong parental PIN	Parental lock enabled	1.Enter wrong PIN	PIN: 0000	Access denied message should display
TC_TV_018	Verify screen rotation support	Verify auto orientation for smart TV apps	Smart TV apps installed	1.Open rotating content app	Gallery App	Orientation should adjust properly
TC_TV_019	Verify TV restart after power cut	Verify TV restarts normally after power outage	TV operating	1.Disconnect power 2.Reconnect power	Power Supply	TV should restart properly
TC_TV_020	Verify overheating handling	Verify TV behavior during long usage	TV ON for long duration	1.Run TV continuously for 8 hours	Continuous Usage	TV should not overheat excessively