

1. List 5 common BIOS or POST error message you might see when starting a PC and write what hardware or configuration issue each one usually points to.



* No Boot Device Found :-

meaning :- PC can't find storage

cause :- Dead drive, loose cable or wrong boot order.

* CMOS checksum Error :-

meaning :- Saved settings were reset

cause :- The tiny round motherboard battery is dead

* CPU Fan Error :-

meaning :- processor cooler isn't working.

cause :- Fan is unplugged, jammed with dust or dead

* RAM / memory test failed :-

meaning :- memory problem detected

cause :- A RAM stick is loose / broken.

* 1 long, 2 short Beeps (No display) :-

meaning :- video connection failed.

cause :- Graphics card is loose / unplugged / faulty

Page No. _____
Date _____

Q. Given the scenario : on boot, a PC beeps 3 times in a repeating pattern and does not display anything on the screen. Research and write what this post beep code typically means for an AMI BIOS, and suggest two troubleshooting steps.

→ 3 beeps on a AMI BIOS indicates a system RAM failure. The PC cannot start because it cannot properly detect / read memory sticks.

* 2 troubleshoot steps :

1. Reset the RAM :-

Turn off PC, unplug it, open case, push RAM stick out from slots, snap them back in tight until side clips click close.

2. Test one stick at a time :-

If you have multiple RAM sticks, remove all but one and try turn on the PC. Switch sticks and slots find out if one specific stick or slot is broken.

3. Access the BIOS setup utility on any available PC or virtual machine, take a screenshot of the main BIOS screen, and identify the motherboard manufacturer and BIOS version.

BIOS Information

BIOS Vendor American Megatrends
 Core Version 5.12
 Compliance UEFI 2.6; PI 1.4
 Project Version 0ACAK 0.20 x64
 Build Date and Time 05/25/2017 10:32:55
 Access Level Administrator

Memory Information

Total Memory 4096 MB (DDR3 1333)

System Language

en (Default)

System Date

[Thu 05/25/2017]

System Time

[15:58:48]

Choose the system
 default language

←→: Select Screen

↑↓: Select Item

Enter: Select

+/-: Change Opt.

F1: General Help

F2: Previous Values

F3: Optimized Defaults

F4: Save & Exit

ESC: Exit

4. you are given a screenshot of a post error message that says 'cmos checksum error - defaults loaded'. Explain what this means and describe how you would resolve this issue in a real system.

→ means :

PC forgot its custom Bios setting (like the date, time and boot order) because memory power was lost. It temporarily loaded factory default settings so the computer can still start.

* How to resolve this issue :-

1. Replace CMOS Battery :-

Unplug PC, open case, swap the dead coin-shaped battery (CR2032) on the motherboard with a fresh one.

2. Re-configure and Save BIOS :-

Turn on PC, press Del or F2 to enter Bios, fix date & time then press F10 to save and exit.