

Sl. No.	Error Description	Error remarks	Error Code
1.	System Status	System OK	0x0001
2.	DEBAR Zone - fire restricted	Fire command in Debar zone	0x0002
3.	Fire aborted	Dynamic accuracy failed (+/- 0.5 Deg)	0x0003
4.	Fire interlocks	Internal interlocks in IRL failed in time of firing	0x0004
5.	R1 Misfired	Fired but still rocket present	0x0005
6.	R2 Misfired	Fired but still rocket present	0x0006
7.	R3 Misfired	Fired but still rocket present	0x0007
8.	R4 Misfired	Fired but still rocket present	0x0008
9.	R5 Misfired	Fired but still rocket present	0x0009

10.	R6 Misfired	Fired but still rocket present	0x0010
11.	R7 Misfired	Fired but still rocket present	0x0011
12.	R8 Misfired	Fired but still rocket present	0x0012
13.	R9 Misfired	Fired but still rocket present	0x0013
14.	R10 Misfired	Fired but still rocket present	0x0014
15.	R11 Misfired	Fired but still rocket present	0x0015
16.	R12 Misfired	Fired but still rocket present	0x0016
17.	Depth setting failed	Depth setting is stopped on some error	0x0017

18.	Throw range invalid for R1 (Note 6)	not a valid throw range	0x0018
19.	Throw range invalid for R2 (Note 6)	not a valid throw range	0x0019
20.	Throw range invalid for R3 (Note 6)	not a valid throw range	0x0020
21.	Throw range invalid for R4 (Note 6)	not a valid throw range	0x0021
22.	Throw range invalid for R5 (Note 6)	not a valid throw range	0x0022
23.	Throw range invalid for R6 (Note 6)	not a valid throw range	0x0023
24.	Throw range invalid for R7 (Note 6)	not a valid throw range	0x0024
25.	Throw range invalid for R8 (Note 6)	not a valid throw range	0x0025

26.	Throw range invalid for R9 (Note 6)	not a valid throw range	0x0026
27.	Throw range invalid for R10 (Note 6)	not a valid throw range	0x0027
28.	Throw range invalid for R11 (Note 6)	not a valid throw range	0x0028