

Kawasaki Motorcycle Owner's Manual

Model: ZX-10R SE 2018

Chapter 1: General Information

This manual is designed to help you get the most enjoyment from your motorcycle. Read this manual thoroughly before operating the motorcycle. Proper maintenance and care will help ensure the reliability and longevity of your vehicle.

The motorcycle is equipped with a 998 cc inline-four engine producing 200 horsepower. The chassis features electronic suspension adjustment and multiple riding modes.

Chapter 2: Controls and Instruments

The instrument panel displays speed, RPM, gear position, and various warning indicators. See Figure 2-1 for the instrument cluster layout.

WARNING: Do not operate the motorcycle if any warning indicator remains illuminated after startup.



Figure 2-1: Instrument Cluster Layout

Chapter 3: Torque Specifications

The following table lists the recommended torque values for common fasteners. Always use a calibrated torque wrench.

Fastener	Torque (Nm)	Location
Oil drain plug	30	Engine bottom
Front axle nut	108	Front wheel
Rear axle nut	108	Rear wheel
Spark plug	13	Cylinder head
Caliper bolt	34	Front brake