

2005 Nissan 350Z VQ35DE — Arnès motor / Engine harness print pack

Motor-control loom on the bench (F-series) · ECM MEC61-510 · 2 páginas: EC-123 + fichas

Card · color = contorno · 5V ámbar / 12V rojo / GND verde · Invertida L/R · FSM EC 2005 · OEM · not a service manual

1 · EC-123 INVERTIDA — MEC61-510 · (misma hoja que la portada)

nº pin arriba · código abajo · borde = cable · rojo = bancada · Invertida L/R

121 RW	120 P	119 RW	113 LG	112 .	111 GYL	110 .	109 WB	108 BR	107 GYR	106 G/OR	6 PL	7 .	8 P	9 SB	10 W/G	11 P	12 L/W	13 WL	14 RL	15 W	16 LG	17 .	18 .	19 .	20 .	21 SB	22 RY	23 RB	24 GY	5 L/Y	4 LB
	118 .	117 GW	105 .	104 SB	103 .	102 BR/Y	101 L/OR	100 .	99 GY	98 G/B	25 P/B	26 .	27 .	28 .	29 .	30 .	31 .	32 BRW	33 R	34 Y/G	35 L/W	36 .	37 .	38 .	39 .	40 LG	41 WB	42 BR	43 .		3 G
116 BR	115 BW	114 .	97 .	96 .	95 .	94 L	93 .	92 .	91 B/OR	90 LG	44 .	45 GW	46 .	47 WR	48 PU	49 B/Y	50 G	51 OR	52 .	53 L/B	54 .	55 L/B	56 WL	57 L	58 W	59 .	60 PUW	61 L/R	62 Y/R	2 GYR	1 B
			89 .	88 .	87 .	86 P	85 LG	84 .	83 G/R	82 GY	63 .	64 .	65 .	66 L	67 BW	68 RW	69 Y	70 G/R	71 .	72 L/W	73 BR/Y	74 OR	75 P/B	76 LG	77 P	78 B/Y	79 GY/R	80 GY	81 G/B		

114-121

1-5

Motor rails · BATT 121=R/W · IGN 119=R/W 120=P · GND 1=B 115=B/W 116=B/R · KNK 15 · CKP 13 · CAN 86/94 · coils/inj · AFh 2/24

6-81

PATH 5V motor · ETC throttle (DBW) · 5V=47 · SNS TPS→66

ETC throttle

DBW · 5V=47 · motor ± · TPS

→47
W/R
5V→4
L/B
M-→5
L/Y
M+SNS
B
GND→69
Y
TZ→50
G
T1

PATH A/F + HO2S · sensores → E12■F3 (heaters / poder) → ECM · heaters ECM 2 / 24

A/F Sens 1 B1

FSM · pass/RH · Inv

→16
LG/B
1fuse
12V
3→35
L/W
5→75
P/B
2→2
GY/R
4→56
W/L
6

A/F Sens 1 B2

FSM · driver/LH · Inv

→76
LG
1fuse
12V
3→55
L/B
5→77
P
2→24
G/Y
4→58
W
6

HO2S2 B1

post-cat RH

fuse
12V
12V→25
PIB
hr

HO2S2 B2

post-cat LH

fuse
12V
12V→6
PIL
hr

A/F heaters / coil-inj 12V rail: E12■F3 (mate en joints abajo)

PATH Knock · sensor → F14/F229 → ECM 15 / GND 116 · otros sensores motor (directo → ECM)

Knock

→F14

→116
B
GND→15
W
SIG

F14

FSM H.S. · GND

→15
W
SIG→116
B
GND

F229

FSM H.S. · GND

→15
W
SIG→116
B
GND

MAF

→ECM 51

→51
OR
SIGgnd
B
GNDpwr
R
12V

CKP POS

→ECM 13

gnd
B
GND→13
W/L
SIG12V
R/W
PWR

CMP B1

cam RH

gnd
B
GND→33
R
SIG

CMP B2

cam LH

gnd
B
GND→14
R/L
SIG

ECT

coolant

SNS
B
GND→73
BR/Y
SIG

IAT

intake air

SNS
B
GND→34
Y/G
SIG

VTC B1

intake cam RH · →ECM 11

ign
R
12V→11
P
ECM

VTC B2

intake cam LH · →ECM 10

ign
R
12V→10
W/G
ECM

Coil 1

→ECM 62

ign
R
12V→62
Y/R
ECM

Coil 2

→ECM 81

ign
R
12V→81
G/B
ECM

Coil 3

→ECM 61

ign
R
12V→61
L/R
ECM

Coil 4

→ECM 80

ign
R
12V→80
GY
ECM

Coil 5

→ECM 60

ign
R
12V→60
PU/W
ECM

Coil 6

→ECM 79

ign
R
12V→79
GY/R
ECM

Inj 1

→ECM 23

ign
R
12V→23
R/B
ECM

Inj 2

→ECM 42

ign
R
12V→42
B/R
ECM

Inj 3

→ECM 22

ign
R
12V→22
R/Y
ECM

Inj 4

→ECM 41

ign
R
12V→41
W/B
ECM

Inj 5

→ECM 21

ign
R
12V→21
SB
ECM

Inj 6

→ECM 40

ign
R
12V→40
LG
ECM

Joints motor · F103/gnd4 → E17 · Ign condenser · SNS GND · E12■F3 · E10■F1 (battery tray)

F103 gnd4

1/115/116 → E17

E17
B
D→116
B/R
C→115
B/W
B→1
B
A

E17 body

ign
gnd

Ign condenser

noise · near cyl3

cyl3
—
→2µF

SNS GND

sensor grounds

→78
B
78→67
B
67→66
B
66

E12

8-pin GY · VB 119/120 · IGN

nc
R/W
BATTnc
—
2JB-15A
R/B
AF/HO2→120
P
VBE7-17
W/L
IGNnc
B
GND→119
R/W
VBnc
—
8

F3

8-pin GY · VB 119/120 · IGN

nc
R/W
BATTnc
—
2JB-15A
R/B
AF/HO2→120
P
VBE7-17
W/L
IGNnc
B
GND→119
R/W
VBnc
—
8

E10

9-pin GY · START · REV Y/R

E4-3
B/Y
STARTE7-26
Y/R
REVJB-15A
R/B
12Vnc
—
4→49
B
SVnc
—
6nc
—
7→67
B/W
GND→70
G/R
SIG

F1

9-pin GY · START · REV Y/R

E4-3
B/Y
STARTnc
Y/R
REVJB-15A
R/B
12Vnc
—
4→49
B
SVnc
—
6nc
—
7→67
B/W
GND→70
G/R
SIG