						Maple HUB								Maple LTE										Maple Sensor													
Model	Model Date Maple HUB SN	Maple Sensor SN	Maple LTE SN	Testing Sever	FW shoulding / Puloro	N F	W fter Motion	Alarm detection	ion LTE	AC power to	to Battery pow	Attach the H	Hub FW (Before	e FW	% Battery	LTE to WiF	to WiFi WiFi to LTE ching switching	LTE Box	LTE battery	AC power to Battery power to AC power switching switching	On-boarding	FW (Before	FW (After	% Ramery	Contact sensor		Temperature sensor			Alarm detection		Decreased	Increased	Accelerometer	Water leak		
						upgr	upgrade) upg)	Smoke (T3) CC	(T4) chargi	charging switching switching	Box (by LTE) up	LTE) upgrad	upgrade)	grade)	switching		Battery SOC	charging		, switching		upgrade)	upgrade)	A Dames y	Move away	Move closer	Check Temperature Room	High temperature detection	Low temperature detection	Smoke (T3)	CO (T4)	brightness	brightness	(Drop)	detection	
MS100	18/09/2022	NA.	NA.	ABBY287WD0351	beta.arlo.com	NA N	A N	IA NA	NA I	NA NA	NA.	NA.	V	V V	V	V	V	V	V	V	V	V	NA.	NA.	NA.	NA.	NA	NA.	NA.	NA.	NA.	NA	NA.	NA.	NA.	NA.	NA.

Temper Motion