				Testing Sever	1	Maple HUB									Maple LTE										Maple Sensor														
Model Date	Maple HUB SN Mapl	Sensor SN M	aple LTE 1		or Onboardin	PW 1 Perform	PW (May	Motion	Alarm detection		TE AC powe	to Battery pos	er Attach the	stach the Hub		FW / Miss	% Rattery	LTE to WiFi WiFi to LT		E LTE Box Battery	LTE	AC power to	Battery power	ar On howeling	FW .	FW (Mass	%	Contact se	ontact sensor Temperature sensor		•	Alarm detec	tion Dr	Decreased Increased Accelerometer Wat	Water leak	Tempe Motion			
						upgrade) upgrade)	s	make (T3) C0	(Y4) charging switch	rging switchi	g switching	Box	(by LTE) upgrade)	upgrade)	switching	switching	soc	charging	switching	switching	o o o o o o o o o o o o o o o o o o o	upgrade)	upgrade)	Battery	Move away Mo	Terr ve doser	Check operature Room	High temperature detection	Low temperature detection	Smoke (T3) C	:O (T4)	ghtness br	rightness	(Drop)	detection	button	
MS1001 19/12/2022	NA A36T	77WD0600	NA	mv.ario.com	NA.	NA	NA	NA	NA.	NA.	NA NA	NA.	NA.	NA	NA	NA.	NA.	NA	NA	NA.	NA.	NA.	NA.	NG	NA	NA	NA	NA.	NA	NA	NA.	NA.	NA.	NA	NA	NA.	NA.	NA.	NA NA