	I	T	FW			ie Testing Sever	1	Maple HUB								Maple LTE										Maple Sensor																
Model	Date	Maple HUB SN		Maple Sensor	Maple LTE SN		Onboardin	FW FW Alarm detection LTE bettery			E AC power	to Batter power to	ry Attac	h the H	ib FW	FW (After	% Battery	LTE to WiFi	WiFi to LTE	TE LTE Box	LTE battery	AC power to	Battery power		FW (Before	FW (After	Cor % Battery		Contact sensor		Temperature ser		Alarm	detection	Decreased	Increased	Acceleromete	Water leak	Temper	Motion		
							9	upgrade )	upgrade )	Sm	oke (T3) O	chargin D (T4) 9	gin power switchin	g switch	er Bo	ix (by	LTE) upgra	upgrade)		switching	switching	Battery SOC	oC charging	switching	switching		upgrade)	upgrade)	Move aw	Move away	Move closer	Check Temperature Room	High temperature detection	Low temperature detection	Smoke (T3)	CO (T4)	brightness	brightness	(Drop)	detection	button	
SH100*	18/06/202	AB512797HD1C11	1.6.2_ee12ab2	NA.	NA h	https://my.arlo.com	V	V	V	V	V	V V	V	V	,	/ !	NA NA	NA.	NA.	NA.	NA.	NA.	NA.	NA	NA	V	NA.	NA.	NA.	NA.	NA.	NA	NA	NA.	NA.	NA.	NA.	NA.	NA	NA	NA	NA.