				I		1	Maple HUB							Maple LTE									Ī	Maple Sensor																
Model	Date	Maple HUB SN	Maple Sensor Sh	N Maple LTE SN	Testing Sever	er Cobouding	FW ing (Before upgrade)	PW (After upgrade)	Ab	Alarm dete	ction L	TE AC power	er to Ba	ttery power Attaci	h the	Hub FW (Before	W FW ifore (After upgrade)	% Battery	LTE to WiFi	WiFi to LT	E LTE Box	x LTE bette	AC power to	Battery power	On-hoarding	FW (Before	FW (After	% Ramery	Contact sensor		Temperature sensor		Alarm detection		Decreased	Increased	Accelerometer	water leak	Temper	
									s	Smoke (T3) CO	O (T4)	arging switch	ing :	switching Bo	g Box (by LTE) upgr	y LTE) upgrade			switching	switching	Battery SOC	charging	switching	ng switching		upgrade)	upgrade)	,	Move awa	y Move closes	Check Temperature Room	High e temperatur detection	Low e temperature detection	Smoke (T3)	CO (T4)	brightness	brightness	(Drop)	detection	button
MS1001	18/09/2022	NA.	A36T277WD060	O NA	beta.arlo.com	NA.	NA	NA	NA	NA.	NA	NA NA		NA N	A	NA NA	NA.	NA.	NA.	NA	NA	NA	NA.	NA.	NG	NA	NA	NA.	NA.	NA	NA.	NA.	NA.	NA	NA.	NA.	NA.	NA.	NA.	NA.

Motion NA