Model	T			Maple LTE SN		1	Maple HUB						Maple LTE										Maple Sensor																		
	Date	Maple HUB SN	Maple Sensor Sh		Testing Sever	ner Onboarding	PW (Before upgrade)	FW (After upgrade)	Motion	Alarm dete	ection	LTE AC por	power to	attery power	Attach the	Hub (I	FW Before	FW After	% Battery	LTE to WiFi	WiFi to LTE	LTE Box	LTE battery	AC power to	AC power to Battery power		FW (Before	FW (After	% Battery	Cor	Contact sensor		Temperature sensor		Alarm detection		Decreased	Increased	Acceleromete	Water leak	Temper
										Smoke (T3) Co	CO (T4)	arging s	witching	switching	Box	(by LTE) up) upg	ipgrade)		switching	switching	Battery SO	charging	switching	switching		upgrade)	upgrade)	,	Move aw	y Move closer	Check Temperature Room	High temperature detection	Low temperature detection	Smoke (T3)	CO (T4)	brightness	brightness	(Drop)	detection	button
MS1001	18/09/2022	NA.	A36T277RD06B	5 NA	beta ario.com	NA.	NA	NA	NA	NA.	NA	NA	NA	NA.	NA.	NA.	NA	NA.	NA.	NA	NA.	NA	NA.	NA	NA	V	V	V	v	V	V	v	٧	V	v	V	v	٧	٧	V	V

