| Model | Date | Maple HUB SN | Maple Sensor SN | FW | Maple LTE SN | Testing Sever | Maple HUB | | | | | | | | | Maple LTE | | | | | | | | | | | Maple Sensor | | | | | | | | | | | | | | | | |
							Onboarding	FW (Before upgrade)	FW (After upgrade)	Motion	Alarm detection Smoke (T3)	Alarm detection CO (T4)	LTE battery charging	AC power to battery power switching	Battery power to AC power switching	Attach the Hub to a LTE Box	Hub online (by LTE)	FW (Before upgrade)	FW (After upgrade)	% Battery	LTE to WiFi switching	WiFi to LTE switching	LTE Box Battery SOC	LTE battery charging	AC power to battery power switching	Battery power to AC power switching	On-boarding	FW (Before upgrade)	FW (After upgrade)	% Battery	Contact sensor Move away	Contact sensor Move closer	Check Temperature Room	High temperature detection	Low temperature detection	Smoke (T3)	CO (T4)	Decreased brightness	Increased brightness	Accelerometer (Drop)	Water leak detection	Temper button	Motion
MS1001	18/06/2023	NA	A36T277RD06B5	2.1.222_879ad62	NA	https://my.arlo.com	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	NA	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V	V