								Maple HUB								Maple LYE									Maple Sensor																		
Мо	iel D	Date Mapi	le HUB SN	Maple Sensor SN	Maple LTE SN	Testing Seve	Cohoustin	FW Inc. / Refere	PW (Mare	Motion	Alarm det	tection LT	E AC pow	er to Batter	ery power A	Attach the	Hub	FW / Refere	FW (Miner)	% Ramery	LTE to WiFi	WiFi to LT	LTE Box	LTE	AC power to	Battery power	On bower	FW .	FW (More	%	Conta	ct sensor		Temperature senso	or	Alarm	detection	Decreased In	creased	Accelerometer	Water leaf	k Tempe	Motion
								upgrade) upgrade	•)	Smoke (T3)	CO (T4) char	ing switch	ing swi	vitching	Box	(by LTE)	upgrade)	upgrade)		switching	switching	9 soc	charging	switching	switching		upgrade)	upgrade)	Battery	Move away	y Move dose	Check Temperature Room	High temperature detection	temperature detection	Smoke (1	F3) CO (F	brightness bri	ightness	(Drop)	detection	button	
MS1	18/0	13/2023	NA A	A36T277WD0600	NA	my.arlo.com	NA.	NA	NA	NA	NA.	NA N	A NA		NA	NA.	NA	NA.	NA.	NA.	NA	NA	NA	NA.	NA	NA	NG	NA	NA	NA	NA	NA	NA	NA.	NA	NA.	NA	NA	NA	NA	NA.	NA.	NA.