Г				Т	ТП	e Testing Sever	1	Maple HUB								Maple LTE										Maple Sensor													
Mode		ate M	aple HUB SN	Maple Sensor SN	Maple LTE SN		Onboardir	PW	FW re (After Motio le) upgrade)	Motio	Alarm detecti	detection	an LTE	AC power to	Battery power	Attach the	Hub F	FW FW		LTE to W	Fi WiFi to LTE	E LTE Box	LTE battery	AC power to	Battery power	Co bossilis	FW FW	. %	(Contact sensor	Temperature sensor		r Alarm detection		Decreased Increase	d Acceleromer	ar Water leaf	Temper M	ntin
								upgrad		Smoke	[T3) CO (T	charging	switching	g switching	LTE Box (t	y LTE) upg	rade) upgra	de)	switching	ning switching	soc	charging	switching	switching		upgrade) upgrad	de) Batter	Mow	away Move clos	Check Temperature Room	High temperature detection	Low temperature detection	Smoke (T3) CO (T	brightness brightne	a (Drop)	detection	button		
MS	1001 19/12	/2022	NA.	A36T277RD06B	NA.	https://my.arlo.com	NA.	NA	NA	NA.	N/	. NA	. NA	NA.	NA.	NA.	NA I	NA NA	. NA	NA.	NA	NA	NA	NA.	NA	٧	v v	V		v v	V	٧	V	V V	V V	v	V	V	v