Model Date			T	Maple LTE	E Testing Sever		Maple HUB								Maple LTE										Maple Sensor													ī				
	Date	Maple HUB SN	Maple Sensor SN			er Osbossii	FW / Refere	FW	Morie	Alarm de	letection	LTE	AC power to	o Battery power for to AC power switching	r Attach the Hub to a LTE Box	Hub	FW FW		6 Battery	LTE to WiFi W	WiFi to LTI	LTE Box	LTE	AC power to	Battery pow	ery power		FW	%	Conta	Contact sensor		Temperature sensor		Alarm detecti		Decrease	d Increase	d Accelerome	ner Water les	Tempe	Motio
						Cilibration	upgrade	upgrade	e)i	Smoke (T	3) CO (T4)	charging (4)	g switching			(by LTE)	i) upgrade)	i) upgrade)	1	switching	switching	SOC	chargin	switching	switching	. Oir-com un	upgrade)) upgrade)	Battery	Move awa	y Move close	Check Temperature Room	High temperature detection	Low temperature detection	Smoke (T	3) CO (T4	brightnes	s brightnes	(Drop)	detectio	button	l
SH1001	18/06/202	AB51277PD0090	NA.	NA.	my.arlo.com	NG	NA.	NA.	NA.	NA.	NA	NA	NA.	NA.	NA.	NA	NA.	NA.	NA.	NA.	NA.	NA	NA.	NA.	NA.	V	NA.	NA	NA	NA.	NA	NA.	NA.	NA.	NA	NA	NA.	NA	NA.	NA	NA	NA.