		Maple N Sensor	Maple LTE SN Testing S		Maple HUB							Maple LTE										Maple Sensor													1						
Model Date	Maple HUB SN			g Sever Onbo	FW ardin (Befo	FW re (After	Metio	Alarm detection Smoke (T3) CO	co (T4)	LTE A	AC power to battery	Battery power to AC	AC Attac	h the	lub (Bel	V FW	v ×	Battery	TE to WiFi	WiFi to LTE	LTE Box	LTE batter	attery ging AC power to bettery power switching	Battery power	On-boarding	FW (Before	FW (After	% Battery	Conta	ctsensor	,	emperature sens	or Alarm detection			Decreased	Increased	Acceleromet	Water leak	Temper	Mo
		J.		'	upgrae )	de upgrade )	le			g g	power switching	power	g Bi	ox (by	LTE) upg	upgra	ide)		switching	switching	Battery SOC	charging		switching		upgrade)	upgrade)		Move away	Move closer	Check Temperature	Check High reperature temperature	Low temperature	Smoke (T3)	CO (T4)	brightness	brightness	(Drop)	detection	button	
H1001 19/12/2022	AB512797HD10	11 NA	NA https://r	rario.com/	v	V	V	V	V	V	V	V	1	V	NA N	A NA	١.	NA.	NA	NA	NA	NA.	NA.	NA.	V	NA.	NA	NA.	NA NA	NA.	NA.	NA.	NA.	NA.	NA NA	NA.	NA.	NA.	NA.	NA.	