_																																									
											Maple HUB					Maple LTE										Maple Sensor															
м	odel	Date Maple HUB	SN Maple Sensor	SN Maple LTE	SN Test	sting Sever	Onboarding	FW (Before	FW (After	Motion	Alarm dete	ction I	TE AC pow	er to Battery power	r Attach the	Hub online	FW ( Before	FW (After	% Battery	LTE to Wif	WiFi to LTE	LTE Box Battery	LTE batter	AC power to battery power	Battery power to AC power	r On-boardin	FW g (Befo	FW re (After	%		ct sensor	1	Temperature senso	и	Alarm detection	on Decr	reased In	ncreased Aco	elerometer	Nater leak Te	mper Motior
								upgrade)	upgrade)	5	imoke (T3)	CO (T4)	rging switch	ning switching	LTE Box	(by LTE	) upgrade	) upgrade	2)	switching	switching	soc	charging	switching	switching		upgrad	ie) upgrade	) Datti	Move away	Move close	Check Temperature Room	High temperature detection	e Low temperature detection	Smoke (T3) CO (	(T4)	Intress Dr	ngraness	(Drop)	setection bu	tton
MS	1001 19/	12/2022 NA	NA	ABB12871D	0846 https://	//my.arlo.com/	NA	NA.	NA	NA	NA.	NA	4A N/	NA NA	V	V	V	V	V	V	٧	V	V	V	V	NA.	NA	NA	N/	A NA	NA.	NA.	NA.	NA NA	NA N	1 AP	NA	NA	NA	NA .	NA NA