										Maple HU								Ma	ple LTE											Maple Sens	Lor							
Model Date Map	Maple I	HUB SN Maple	Sensor SN	Maple LTE SN	Testing Sever		FW parding (Before upgrade)	FW	Motion	Alarm detection	ion LTI	AC power	o Battery powe	Attach the	he Hub	% Rame	LTE to V	WiFi WiFi to	LTE B	ox LTE	E AC power	to Battery pow	er	FV	v FW	%	Contact sensor		Temperature sensor		,	Alarm de		Decreased	Increased	Acceleromet	water leaf	Tempe
						Onboardin		de) upgrade	50)	Smoke (T3)	charg	ng switching	switching	Box	(by LT	TE)	switchin	ing switchi	ng Soc	chargi	ing switchin	g switching	- Circulati	upgra	ide) upgrade	Battery	Move awa	Move dose	Check Temperature Room	High temperature detection	Low temperature detection	Smoke (T3	CO (T4)	brightness	brightness	(Drop)	detection	button
31001 18/06/2023	3 1	NA.	NA	ABBY287WD0351	my.arlo.com	NA.	NA	NA	NA	NA	NA NA	NA.	NA	V	NG	V	NG	NG	V	V	V	V	NA	N/	A NA	NA	NA.	NA.	NA.	NA.	NA	NA	NA.	NA.	NA	NA	NA.	NA N