						_								_																												_
					Testing Sever		Maple HUB							Maple LTE									Maple Sensor																			
м	Model Date Maple HL	Date Maple HUB S	N Maple Sensor S	N Maple LTE SN		Onboarding	FW ( Before	FW (After	Motion	Alarm detection		LTE AC power to Battery por		power A	r Attach the	Hub	FW ( Refore	PW ( Mter	% Batter	tery LTE to WiFi		LTE Box	LTE battery	AC pow	wer to Batt	tery power	On-boarding	FW ( Refer	FW FW			tact sensor	Temperature ser		or	Alarm detection	n Decrea	ased Incr	eased Accelerome	ter Water	leak Temps	er Motior
							upgrade) upgrade)	0 .	Smoke (T3) CO (T4) charging switching switching		hing	LTE Box	(by LTE	upgrade	) upgrade	0	switching	switching	soc	chargin	ng switch	switching switching			upgrad	le) upgrade	() Batt	Move as	ray Move clos	Check Temperature	High temperature detection	Low temperature detection	Smoke (T3) CO (	[Y4] brightn	ness brig	htness (Drop)	detect	tion butto	a			
MS	1001 18/	03/2023 NA	NA.	ABB12871D084	https://my.arlo.com	NA.	NA.	NA	NA	NA.	NA	NA	NA N	A	V	V	V	V	V	V	V	V	V	V	V	V	NA.	NA	NA	N	A NA	NA.	NA.	NA.	NA	NA NA	A NA	Α Ι	NA NA	N/	A NA	NA.