Г					Maple LTE SN			Maple HUB								Maple LTE										Maple Sensor												$\neg$		
	odel Date	Maple HUB SI	N Maple Sensor SN	FW		Testing Sever	Onboarding	FW	FW ( May	Motion	Alarm detection	tion LTE	AC power to	Battery power	r Attach the	Hub	FW (Refere	FW % F	tomory L	TE to WiFi	Fi WiFi to LT	LTE Box	LTE	AC power to	o Battery pow	ar On beautio	FW ( Perform	FW ( May	*	Contact sensor		Temperature sensor			Alarm detection	Decreased	Increased	Accelerometer	Water leak	Temper Morie
								upgrade)	upgrade)		imoke (T3)	O (T4)	ng switching	switching	LTE Box	(by LTE	upgrade) up	grade)		switching	switching	soc	charging	switching	switching		upgrade) u	apgrade)	Battery	Move away	Move closer	Check Temperature Boom	High temperature detection	Low temperature detection	Smoke (T3) CO (T4	brightness I	brightness	(Drop)	detection	button
M	1001 18/03/202	3 NA	A36T277RD06B5	2.1.222_879ad62	NA.	https://my.arlo.com/	NA	NA.	NA.	NA	NA	NA NA	NA.	NA.	NA.	NA.	NA	NA	NA	NA	NA.	NA.	NA.	NA.	NA.	V	V	V	V	V	V	v	V	V	V V	V	V	V	V	V V