							_																																			
Mode								Maple HUB								Maple LTE									Maple Sensor																	
	odel	Date Maple HUB S	IB SN Map	sple Sensor SN	Maple LTE SN	Testing Sever	or Onboardin	FW / Refere	W FW Motio		Alarm detection		LTE AC power to Battery powe		Attach the	Hub	FW / Refere	PW (Mare	% Batter	v LTE to W	iFi WiFi to LTI	LTE Box	ox LTE batter	AC power t	o Battery pow	er . On howefu	FW / Refer	FW (Mass	%	Conta	ct sensor	Temperature sens		ior	Alarm di	Alarm detection		Increased	Acceleromete	Water leak	Temper Motion	
								upgrade)	ide) upgrade)	2)	Smoke (T3) CO (T4) charging switching	switching	switching	LTE Box	(by LTE) upgrade) upgrade	switching	g switching	soc	charging	switching	switching	ing	upgrad	upgrade	Battery	Move awa	Move dose	Check Temperature Room	Check High temperature Low temperature Room detection detection		¹⁰ Smoke (T3) CO (T4)	brightness brig	brightness	(Drop)	detection	button			
MS	1001 18	3/06/2023 NA		NA	ABB12871D0846	https://mv.arlo.com	NA.	NA	NA	NA.	NA	NA	NA.	NA.	NA	٧	V	V	V	V	V	v	V	V	v	V	NA.	NA	NA	NA	NA	NA	NA.	NA.	NA.	NA.	NA	NA.	NA	NA.	NA	NA NA