

CAR MAINTENANCE FOR SOLO DRIVERS

Roadside Independence and Safety

Quick Access

The Emergency Kit

Changing a Flat Tire

Jump-Starting Safely

Checking Oil & Fluids

Breakdown Safety Rules

The Emergency Kit

Keep these in your trunk at all times:

- Jumper Cables or Lithium Jump Starter
- Flashlight & Spare Batteries
- Reflective Triangle
- Tire Pressure Gauge
- Portable Phone Charger

How to Change a Flat Tire

Loosen: Before jacking up the car, loosen the lug nuts (counter-clockwise).

Jack: Position the jack under the frame and lift the car.

Swap: Remove nuts, pull off the flat, and push on the spare.

Tighten: Replace nuts by hand. Lower the car, then tighten fully with the wrench in a star pattern.

Jump-Starting Your Car

The Connection Order (Vital!):

1. Red clip to **Dead** (+)
2. Red clip to **Live** (+)
3. Black clip to **Live** (-)
4. Black clip to **Unpainted Metal** on dead car.

Never let the metal clips touch each other once connected to a battery!

What to Do if You Break Down

- Get off the road as far as possible.
- Turn on hazard lights and pop the hood.
- If on a highway, stay inside the car with your seatbelt on.
- Call for help from your car.