HDMI EXTENSION BOARD — SCH6313 CONNECTIONS, POWER AND MOUNTING

Power Jack

12 V nominal center-positive

J1

SCH6313 MODULE MOUNTING HOLES

FRONTEND 5 V POWER | CUSTOM MICRO-HDMI PORTS — NOT STANDARD HDMI

USB-C JTAG PROGRAMMER, SELECTION AND FRONTEND PORTS

USB TO JTAG PROGRAMMER

CUSTOM FRONTEND INTERFACE — NOT HDMI VIDEO

FRONTEND PORT 0 — J1 · JTAG SWITCH + MICRO-HDMI

FRONTEND PORT 1 — J2 · JTAG SWITCH + MICRO-HDMI

FRONTEND PORT 2 — J3 · JTAG SWITCH + MICRO-HDMI

FRONTEND PORT 3 — J4 · JTAG SWITCH + MICRO-HDMI

FRONTEND PORT 4 — J5 · JTAG SWITCH + MICRO-HDMI

FRONTEND PORT 5 — J6 · JTAG SWITCH + MICRO-HDMI

FRONTEND PORT 6 — J7 · JTAG SWITCH + MICRO-HDMI

FRONTEND PORT 7 — J8 · JTAG SWITCH + MICRO-HDMI

PCIe x4 — BM8510 reference circuit