

R3WRK - MIDI CC Chart

Every knob and button has a fixed CC number. R3WRK listens on the MIDI channel set in Tools > MIDI Channel (default 1, or Omni). Knobs: CC 0-127 covers the knob's full travel and CC 64 is exactly its centre. Buttons act when pressed (value 64 or more) and ignore the release.

Transport

CC	Control	Type	Range / behaviour
9	Monitor DRY / FX	button	press: switch
88	Loop crossfade	knob	0 .. 50 ms
89	Auto-Record threshold	knob	-60 .. 0 dB
102	Play / Stop	button	press: play, or stop (also stops a recording)
103	Play from start	button	press: restart from the beginning
104	Record	button	press: start / stop recording
105	Loop mode	button	press: off > loop > ping-pong > reverse > off
106	Overdub	button	press: start / stop an overdub pass
107	Monitor	button	press: on / off
108	Auto-Record	button	press: arm / disarm

Knob row (Pitch / Speed / Stretch, Dirt, filter, Start / End)

CC	Control	Type	Range / behaviour
14	Pitch	knob	-12 .. +12 semitones (64 = 0)
15	Speed	knob	0.25x .. 4x tape speed (64 = 1x)
16	Stretch	knob	0.25x .. 50x (64 = 1x)
17	Dirt (Drive)	knob	off .. 100%
18	Base	knob	filter high-pass corner (0 = off)
19	Width	knob	filter low-pass above Base (127 = open)
20	HP Q	knob	0 .. 100% resonance
21	LP Q	knob	0 .. 100% resonance
22	Start	knob	selection start (slides the whole selection)
23	End	knob	selection end
24	Dirt Rate	knob	sample-rate reduction (127 = clean)
25	Dirt Bits	knob	bit reduction (127 = clean)
109	Filter on/off	button	press: on / off (knobs keep their settings)
110	Filter model	button	press: OT <> MNM

Output

CC	Control	Type	Range / behaviour
7	Gain	knob	-inf .. +12 dB (master volume, last in the chain)

FX drawer - slot 1 (RTRG / CHO)

CC	Control	Type	Range / behaviour
111	RTRG <> CHO	button	press: switch the slot
112	Slot 1 on	button	press: RTRG latch / CHO on-off

RTRG - buffer retrig

CC	Control	Type	Range / behaviour
8	Sync / Free	button	press: switch
48	Time	knob	note value (Sync) or 10 ms .. 1 s (Free)
49	Fade	knob	64 = plain repeats, below fades out, above builds up

CHO - chorus (values are the Monomachine's raw 0-127)

CC	Control	Type	Range / behaviour
40	DEL	knob	0 .. 127 (same as the MnM)
41	DEP	knob	0 .. 127
42	SPD	knob	0 .. 127
43	MIX	knob	0 .. 127
44	FB	knob	0 .. 127
45	WID	knob	0 .. 127
46	LP	knob	0 .. 127
47	INP	knob	0 .. 127

FX drawer - slot 2 (DLY / PLX)

CC	Control	Type	Range / behaviour
113	DLY <> PLX	button	press: switch the slot
114	Slot 2 on	button	press: on / off (off lets the tail ring out)

DLY - delay

CC	Control	Type	Range / behaviour
50	Zone	knob	8 zones across the travel
51	Rate	knob	0 .. 100%
52	Repeats	knob	0 .. 100%
53	Color	knob	64 = neutral
54	Halo	knob	0 .. 100%
55	Mix	knob	0 .. 100%
56	Skew	knob	64 = centre
119	Ping-Pong	button	press: on / off

PLX

CC	Control	Type	Range / behaviour
57	Level	knob	0 .. 100%
58	Plexus	knob	0 .. 100%
59	Size	knob	0 .. 100%
60	Diffuse	knob	0 .. 100%
61	Decay	knob	0 .. 100%
62	Color	knob	64 = neutral
63	Mix	knob	0 .. 100%
70	Couple	knob	0 .. 100%
71	Skew	knob	64 = centre

FX drawer - slot 3 (RVB / SHM)

CC	Control	Type	Range / behaviour
115	RVB <> SHM	button	press: switch the slot
116	Slot 3 on	button	press: on / off (off lets the tail ring out)

RVB - reverb

CC	Control	Type	Range / behaviour
72	Size	knob	0 .. 100%
73	Absorb	knob	0 .. 100%
74	Decay	knob	0 .. 100%
75	Tilt	knob	64 = flat
76	Mix	knob	0 .. 100%
77	Pre-delay	knob	7 .. 500 ms
78	Width	knob	0 .. 200% (64 = 100%)

SHM - shimmer reverb

CC	Control	Type	Range / behaviour
79	Size	knob	0 .. 100%
80	Decay	knob	0.3 .. 20 s
81	Tone	knob	below 64 low-pass, above high-pass
82	Shimmer	knob	0 .. 100%
83	Movement	knob	0 .. 100%
84	Width	knob	0 .. 100%
85	Mix	knob	0 .. 100%
117	Freeze	button	press: on / off
118	Interval	button	press: octave <> fifth

Overdub

CC	Control	Type	Range / behaviour
86	Level	knob	-inf .. +6 dB
87	Feedback	knob	0 .. 100%

Tools

CC	Control	Type	Range / behaviour
10	Scrub mode	button	press: on / off (window open)
11	Slice mode	button	press: on / off (window open)
12	Record Desktop	button	press: start / stop (Standalone, window open)
13	Capture Output	button	press: start / stop (Standalone, window open)
26	Clear	button	press: clear the waveform (window open)
27	Reset (bolt)	button	press: stop + every knob and effect to default

Setup

Ableton Live (VST3): on a MIDI track, set MIDI From to your controller and MIDI To to the track with R3WRK (pick R3WRK in the second menu). Set the MIDI track's Monitor to In (or arm it). Works with R3WRK's window closed.

Standalone: R3WRK menu > Audio Settings, tick your controller under Active MIDI inputs.

Channel: Tools > MIDI Channel (Standalone: R3WRK menu > MIDI Channel). Remembered across sessions.

Window-only buttons: Scrub, Slice, Clear, Record Desktop and Capture Output only respond while R3WRK's window is open.