10734

CONTINUED FROM DTX36IU/1.

TURNHEAD CONTACTOR
24, 215, 28

POSITION RELAY Nº1
163,171, 232, 292, 361

POSITION RELAY Nº2
164,173, 227, 360, 543

POSITION RELAY Nº3
165,175, 229, 295, 358

POSITION RELAY Nº4
166,177, 294,359 233

POSITION RELAY Nº5
167, 179,

POSITION RELAY Nº6
168, 181, 231, 355, 358

POSITION RELAY Nº7
169, 183, 297, 356

POSITION RELAY Nº8
170,185,228, 674

TURNHEAD RELAY
153, 158, 202, 204.

INDICATION RELAY Nº1
187, 204, 26, 232, 361, 298, 155 543

INDICATION RELAY Nº2
188,205,217, 227, 588 · 360 156

INDICATION RELAY Nº3 & 3A
192, 206, 218, 229, 294, 359, 496, 589
702. 157

INDICATION RELAY Nº4
194, 207, 219, 294 359 158 233
349F

INDICATION RELAY Nº5
195, 208, 220, 159

INDICATION RELAY Nº6
196, 209, 221, 231, 295, 355, 160

INDICATION RELAY Nº7
197, 210, 216, 297 161 349C
356

INDICATION RELAY Nº8
198, 211, 217, 228, 703· 162, 676

LOWER GARNER CLOSE RELAY
101, 108, 108, 204.

LOWER GARNER OPEN RELAY
109

AUTO RELAY
83, 84, 85, 204, 205, 211.

STOP RELAY Nº9
182, 177, 184.

TURNHEAD SHOWN BETWEEN POSITIONS

TURNHEAD SHOWN ON POSITION 4.

TURNHEAD CONTACTOR
280, 281, 284

POSITION RELAY Nº1
156, 294, 241, 360, 543

POSITION RELAY Nº2
162, 235, 243, 676

POSITION RELAY Nº3
157, 236, 245, 296 358

POSITION RELAY Nº4
237, 247.

POSITION RELAY Nº5
160, 238, 249, 298 358

POSITION RELAY Nº6
138, 239, 251, 298, 361

POSITION RELAY Nº7
159, 240, 253, 359 294

TURNHEAD RELAY
225, 290, 273, 272

INDICATION RELAY Nº1
186, 258, 273, 282, 360, 590, 227 543

INDICATION RELAY Nº2
162, 262, 274, 283, 704, 228, 676

INDICATION RELAY Nº3 & 3A
157, 263, 275, 284, 296, 358, 497, 591, 705, 281

INDICATION RELAY Nº4
268, 276, 285, 230 284, 287

INDICATION RELAY Nº5
160, 269, 277, 286, 299 358 234

INDICATION RELAY Nº6
188, 270, 278, 287, 292, 361 236

INDICATION RELAY Nº7 349G
158, 271, 279, 282, 359, 233, 294

AUTO RELAY
223, 224, 223, 257, 273, 283.

STOP RELAY Nº10
224, 265, 226.

LOWER GARNER CLOSE RELAY
126, 129, 132, 273.

LOWER GARNER OPEN RELAY
128

Contacts N/C 41R4 {TH4 / IR4}
691● & 692● Cables shorted out
Contacts N/C 41R4 {TH4 / IR4}
693●&694● Cables shorted out
28-11-74

TURNHEAD CONTACTOR
342, 343, 344

POSITION RELAY Nº1
155, 232, 299, 304, 361

POSITION RELAY Nº2
162, 231, 300, 308, 355

POSITION RELAY Nº3
301, 310, 359 158 233

POSITION RELAY Nº4
303, 312.

POSITION RELAY Nº5
157, 229 308, 314, 358.

POSITION RELAY Nº6
161, 304, 316, 356

POSITION RELAY Nº7
305, 318, 364, 471

TURNHEAD RELAY
291, 292, 338, 351

INDICATION RELAY Nº1
186, 232, 320, 338, 344, 364, 298

INDICATION RELAY Nº2
162, 231, 321, 334, 345, 358 ; 676

INDICATION RELAY Nº3
158, 322, 336, 346, 359 496 233 349D

INDICATION RELAY Nº4
323, 336, 347, 348, 349 · 296

INDICATION RELAY Nº5
157, 229, 324, 337, 348 358 498 588/700 674

INDICATION RELAY Nº6
161, 326, 338, 349. 677 349A 356

INDICATION RELAY Nº7
327, 339, 344, 364 498 588/677
LOWER GARNER CLOSE RELAY
34, 37, 60, 333.

LOWER GARNER OPEN RELAY

AUTO RELAY
223, 224, 225, 253, 273
STOP RELAY Nº9
303, 312, 284.

IN MCC13

TPA AT RCC8

WHAT RCC8

LGV ENABLE OPEN
1TPC POS RCC8
136 225 232 298
LGV ENABLE OPEN
1TPA POS RCC8
132 226 234

LGV INTERLOCK FROM MCC13

Contacts N/C 11R4 {TH4 / IR4}
302●&303● Cables shorted out
322●&323● Cables shorted out

NOTE - 'IR' Relays are Turnhead position relays

10734

SCHEME FOR MCC3B - SEAFORTH GRAIN TERMINAL

REVISION 12
Notes added re-shorting out cables
691 & 692. 693 & 694
302 & 303. 322 & 323
2-12-76

REV. 10
STOP RELAY CONTACT ADDED TO TURNHEAD POSITION RELAY CIRCUIT.

REVISION: 9
REVISION: 8
REVISION: 7
REVISION: 6
REVISION: 5
REVISION: 4
REVISION: 3
REVISION: 2
REVISION: 1

THE DESIGN AND MANUFACTURING INFORMATION CONTAINED IN THIS DRAWING IS THE EXCLUSIVE ASSENT OF DEWHURST & PARTNER LTD. AND MUST NOT BE COPIED OR USED FOR MANUFACTURING PURPOSES.

ISSUE 1 2 3 4 5 6 7 8 9 10 11

DTX36IU/2.

DRAWN BY J.F
DATE 16-12-70
CHECKED BY
APPROVED BY
DATE

KEY DIAG. No.
EXT. DIAG. No.
REL. DIAG. No.
PANEL LAYOUT No.

DTX36IU/2.

DEWHURST & PARTNER LTD.
MELBOURNE WORKS HOUNSLOW

TITLE: SCHEME FOR MCC3B - SEAFORTH GRAIN TERMINAL.