

HydroModPy

watershed.csv
name ; x_coord ; y_coord

watershed.py

Build()

create_object()

geographic.py

Extract()

- generate_files()
- load_files()

geology.py

Extract()

- generate_structure_dem()
- geology_array()
- geology_elevation()
- geo_to_K()

oceanic.py

Extract()

- mean_sea_level()
- rise_sea_level()
- idx_from_global_map()
- display_data() — display_oceanic.py

piezometry.py

Extract()

- download_init()
- extract_piezors_from_watershed()
- extract_data_from_code_bss()
- load_piezometric_data()
- add_piezometry_data()
- add_data()

hydrology.py

Extract()

- clip_observed()

climatic.py

Extract()

- extract_cells_from_shapefile()
- extract_values_from_h5file()
- display_all_variables() — display_climatic.py
- display_intermensual_scenarios() — display_climatic.py
- display_annual_scenarios() — display_climatic.py
- display_anomaly() — display_climatic.py

hydrodynamic.py

load_object()

save_object()

python_object

run_flow()

modflow.py

RunModel()

build_modflow_model()

- param()
- watertable_depth()
- watertable()
- seepage()
- gwflux()
- outflow()
- spedish()

ExtractModel()

watershed.data

watershed.params

calib_strats.csv
list of strategies
obs_data ; hom_het ; state
params_to_calibrate.csv

calib_strategies.py

CalibStrategies()

load_strategies()

check_strategies()

run_strategies()

définition paramètres

calib_params.py

CalibParams()

- load_params()
- create_params()
- save_params()

définition fonction objectif

calib_objective_function.py

fo_stream_het_SS_calibration()

définition de la méthode de la calibration

calib_main.py

run_calibration() — minimize_