


Symbol	Description
*** 	"Coil" The state of the left hand connection is copied to the boolean variable and to the right hand connection.
*** 	"Negative Coil" The state of the left hand connection is copied to the right hand connection. The inverse state of the left hand connection is copied to the associated boolean variable i.e. if the state of the left hand connection is OFF the state of the associated variable is set to ON and vice versa
*** 	"SET coil" The associated boolean variable is SET to the ON state, if the left hand connection is in the ON state and remains set until the coil is RESET.
*** 	"RESET coil" The associated boolean variable is RESET, if the left hand connection is in the ON state and remains reset until the coil is SET.