



- ADD_I : Add Integer
- SUB_I : Subtract Integer
- MUL_I : Multiply Integer
- DIV_I : Divide Integer

Parameter English	Data Type	Memory Area	Description
no.	COUNTER	C	Counter identification number. The range depends on the CPU.
CU	BOOL	I, Q, M, D, L	ZV input: Up Counter
CD	BOOL	I, Q, M, D, L	ZR input: Down Counter
S	BOOL	I, Q, M, D, L, T, C	Input for presetting the counter
PV	WORD	I, Q, M, D, L or constant	Count value in the range between 0 and 999 or Count value entered as C#<value> in BCD format
R	BOOL	I, Q, M, D, L, T, C	Reset input
CV	WORD	I, Q, M, D, L	Current count value (hexadecimal number)
CV_BCD	WORD	I, Q, M, D, L	Current count value (BCD format)
Q	BOOL	I, Q, M, D, L	Status of the counter

Parameter	Data Type	Memory Area	Description
EN	BOOL	I, Q, M, D, L, T, C	Enable input
IN1	DINT	I, Q, M, D, L or constant	First value for addition
IN2	DINT	I, Q, M, D, L or constant	Second value for addition
OUT	DINT	I, Q, M, D, L	Result of addition
ENO	BOOL	I, Q, M, D, L	Enable output