ASSIGNMENT-4

Date	02 OCTOBER 2022
Team ID	PNT2022TMID19800
Project Name	SmartFarmer - IoT Enabled Smart Farming Application
Student name	DHINESH KUMAR R
Roll number	727819TUIT012

Write Code and connections in wokwi for ultrasonic sensor. whatever distance is less than 100 cms send "Alert" to ibm cloud aand display in device recent events

CODING:

```
//Pins

const int TRIG_PIN = 7;

const int ECHO_PIN = 8;

//Anything over 400 cm (23200 us pulse) is "out of range"

const unsigned int MAX_DIST = 23200;
```


```
void setup() {
// The Trigger pin will tell the sensor to range find
Pin Mode(TRIG PIN, OUTPUT);
digital Write(TRIG_PIN, LOW);
//Set Echo pin as input to measure the duration of
//pulses coming back from the distance sensor
pinMode(ECHO PIN, INPUT );
// We'll use the serial monitor to view the sensor output
Serial.begin(9600);
void loop() {
unsigned long t1;
unsigned long t2;
unsigned long pulse_width;
float cm;
float inches;
```

```
// Hold the trigger pin high for at least 10 us
digitalWrite(TRIG PIN, HIGH);
delayMicroseconds(10);
digitalWrite(TRIG PIN, LOW);
// Wait for pulse on echo pin
while (digitalRead(ECHO PIN)==0);
// Measure how long the echo pin was held high (pulse width)
// Note: the micros() counter will overflow after-70 min
t1= micros ();
 while (digitalRead(ECHO PIN) == 1);
 t2 = micros();
 pulse_width = t2-t1;
// Calculate distance in centimeters and inches. The constants
//are found in the datasheet, and calculated from the assumed speed
// of sound in air at sea level (- 340m/s)
cm=pulse Width / 58;
inches = pulse width/148.0;
```

```
// Print out results
if (pulse_width >MAX _ DIST ){
Serial.println("Out of range");
} else {
Serial.println("*********************************);
Serial.print("The Measured Distance in cm: ");
Serial.println(cm);
if( cm < 100 ){
  //while(true){
   Serial.println("Alert!!");
   //}
//wait at least 1000ms before next measurement
Delay(1000);
```

OUTPUT:

1.If the distance is less than 100 cms, it alerts.



Activate Window

2.If the distance is more than 100 cms, it won't alert

```
WOKWI B SAVE - SHARE
hc-sr04.ino diagram json ● Library Manager ▼
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                     ⊙00:00.599 ⊘62%
                                 const int TRIG_PIN = 7;
                                 const int ECHO_PIN = 8;
                                 // Anything over 400 cm (23200 us pulse) is "out of range"
                                 const unsigned int MAX_DIST = 23200;
                                      // The Trigger pin will tell the sensor to range find
                                                                                                                                                                                                                                                                                                                                                                                            STATE OF THE PARTY OF THE PARTY
                                     pinMode(TRIG_PIN, OUTPUT);
                12
                                    digitalWrite(TRIG_PIN, LOW);
                                                                                                                                                                                                                                                                                                                                                                                          OO UNO
                13
                                //Set Echo pin as input to measure the duration of 
//pulses coming back from the distance sensor 
pinMode(ECHO_PIN, INPUT);
              15
16
              18
19
                                   // We'll use the serial monitor to view the sensor output
Serial.begin(9600);
              28
                                                                                                                                                                                                                                                                                                                                                                                                        illan and
                                 void loop() {
              23
24
                                        unsigned long t1;
                                                                                                                                                                                                                                                                                                             .......
                25
                                         unsigned long t2;
                                                                                                                                                                                                                                                                                                             The Measured Distance in cm : 227.10
                                        unsigned long pulse_width;
float cm;
float inches;
              26
27
                                                                                                                                                                                                                                                                                                             .......
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      Activate Windows
                                                                                                                                                                                                                                                                                                                                                                                                                                                                                      Go to Settings to activate Windows.
```

3.Simulation and code execution

