


OUTPUT



1) when distance under 100 cm it wil show normal distance





Sending payload: {"Alert distance":106.98}
Warning crosses 110cm -- it automaticaly of the loop

Sending payload: {"Alert distance":106.98}
Warning crosses 110cm -- it automaticaly of the loop

Sending payload: {"Alert distance":106.98}
Warning crosses 110cm -- it automaticaly of the loop

Sending payload: {"Alert distance":106.98}
Warning crosses 110cm -- it automaticaly of the loop

Sending payload: {"Alert distance":106.98}
Warning crosses 110cm -- it automaticaly of the loop

Sending payload: {"Alert distance":106.98}
Warning crosses 110cm -- it automaticaly of the loop

2) when distance cross 100 cm it wil show ALERT with warning message distance

when it cross above 110 cm it totaly move to iff state once it reduce to 110 it on again

IBM CLOUD OUPUT

Recent Events The recent events listed show the live stream of data that is coming and going from this device

Event	Value	Format	Last Received
Data	{"Normal Distance":89.95}	json	a few seconds ago
Data	{"Normal Distance":89.95}	json	a few seconds ago
Data	{"Normal Distance":89.95}	json	a few seconds ago
Data	{"Normal Distance":89.95}	json	a few seconds ago
Data	["Normal Distance":89.95]	json	a few seconds ago

Recent Events

The recent events listed show the live stream of data that is coming and going from this device.

Event	Value	Format	Last Received
Data	{"Alert distance":106.98}	json	a few seconds ago
Data	{"Alert distance":107.03}	json	a few seconds ago
Data	{"Alert distance":106.98}	json	a few seconds ago
Data	{"Alert distance":106.98}	json	a few seconds ago
Data	{"Alert distance":106.98}	json	a few seconds ago