How do I install my router using the router web interface?

Contents

How do I install my router using the router web interface?	1
Basic installation of your router using the router web interface:	2
Firmware Update section (as part of Basic Installation):	
How do I change my router's WiFi password or network name (SSID)?	3

Basic installation of your router using the router web interface:

- 1. Using an Ethernet cable, connect your modem to the yellow Internet port on the back of your router.
- 2. Connect your computer to one of the **Ethernet** ports on your router.
- 3. Press the **Power** button on the router.

The LEDs on the router light.

4. Open a web browser and enter rogin.net.

You are prompted to log in.

5. Log in to the router.

The default user name is **admin**. The default password is **password**.

The user name and password are case-sensitive.

- 6. Click ADVANCED > Setup Wizard.
- 7. Select the Yes radio button and click Next.

The router detects your Internet connection.

You are prompted to log in.

- 8. Enter and confirm a new admin password.
- 9. Select and answer two security questions.
- 10. Click Next.

The Congratulations! page displays.

- 11. (Optional) Click **Print this** to print your network settings.
- 12. Click Next for Firmware update

Firmware Update section (as part of Basic Installation):

The Firmware Update Assistant page displays.

13. If a firmware update is not available, click OK.

Your router is set up.

14. If a firmware update is available, click **Yes** to update your firmware.

The firmware updates.

The router reboots.

You are prompted to log in.

15. Enter admin and the new password you created earlier.

The BASIC page displays.

Your router is set up.

How do I change my router's WiFi password or network name (SSID)?

- When you set up a new router for the first time, it is configured with factory default settings, including a default WiFi network name (SSID) and password. The default settings are located on a sticker on your router.
- You can optionally change the default WiFi password or SSID during initial setup. If you kept
 the default settings but want to change them to something else after setup, you can do so
 from the router web interface.
- The WiFi password and SSID is not the same as the admin password that you use to log in to the router web interface

To change your router's WiFi password or network name (SSID):

- 1. Launch a web browser from a device that is connected to your router's network.
- 2. Enter www.rlogin.net.

A login window displays.

3. Enter your user name and password.

The default user name is **admin**. The password is the one that you specified the first time that you logged in. The user name and password are case-sensitive.

- 4. The BASIC Home page or Dashboard displays.
- Select Wireless.

For Gaming routers, select **Settings > Wireless Setup**.

- 6. Enter your new network name in the **Name (SSID)** field.
- 7. Enter your new password in the **Password (Network Key)** fields.
- 8. Click or tap **Apply**.

Your changes are saved.

If your device disconnects from your WiFi network after saving your changes, view the available wireless networks again and reconnect using the new WiFi network key or password.